

Zebra Aurora™ MV/FIS Configuration Utility

Description

Product Description

Zebra Aurora™ is a host-side application which allows for the configuration Zebra FS10, xS20, xS40 and xS70 devices.

Device Compatibility

Zebra Aurora™ can be used to program Zebra MV/FIS devices through these programming modes:

- USB connected cable
- M12 Ethernet

Supported Devices	Supported Device FW
FS40, VS40, FS70, VS70	CAAESS00-001-R34
FS10, FS20, VS20	CAAFFS00-001-R34

Release Notes

This document summarizes the following software release:

Software Version Number	Release Date
V2.0.8000	April 2022

V2.0.8000

RELEASE DATE: APRIL 2022

- Performance and Stability Enhancements

V2.0.7000

RELEASE DATE: MARCH 2022

- Performance and Stability Enhancements
- 1D Barcode Quality Metrics
- Added Object Locate Plus
- Added Blob Tools
- Added Binarize Filter/Tool
- Added Dilate Filter/Tool
- ImagePerfect(+) fixes & improvements
- Added Scale Calibration for Distance tool
- Added Advanced Pass/Fail Configuration (AND/OR logic for Job results)
- HID Keyboard Expansion – added French and German KB
- Added support for Codabar symbology
- Added Encoding type (Text/Base64) for ADF Full String data type and added option to show non-printable characters as hex values
- For xS10/20, added external illumination support
- Added “File Path” option when using (S)FTP to Save images
- Added Ability to Open a Local Job (created with emulator) On a Real Connected Camera

V1.200.2001

RELEASE DATE: DECEMBER 2021

- Performance and Stability Enhancements
- Support for 5MP xS40 and xS70 models
- ImagePerfect(+) for FS models
- Option to output Barcode Location Co-ordinates
- Option to not read last n number of barcodes
- Device can be a TCP/IP Client
- Configurable RS-232 settings
- Ability to configure GPIO Trigger delay
- Support for Fast Hardware Trigger (2.3 MP models only)
- Ability to set GPIOs to static high or low
- Added Job controls to clone, rename and delete jobs
- Support for Conditional Regular expressions for Barcode String Match

- Barcode String Match Regular expression support for ManyCode
- Backwards compatibility of Job files
- Decode and MV statistics in Aurora and HMI stored and queried from device

V1.148.0001

RELEASE DATE: OCTOBER 2021

- Performance Enhancements
- Stability Improvements
- Implementation of licensing error messages in Web HMI
- Fixed issue of Job pausing on refresh of Web HMI
- Fixed issue of crash when clicking on "Communications" tab
- Fixed inability to "View" active Jobs from Job menu when Job utilizes a trigger that is automatic in nature.
- Fixed issue of slow decode rate when "Fast 1D/2D" license is enabled
- Added Configurable TCP/IP – results port and trigger string can be configured
- Support for GPIO > Hardware trigger (normal speed)
- Allow setting a job as Startup / Power up job
- Emulators now have license level
- Supports a total of 21 emulators
- ZJOB backwards compatibility and auto conversion of old job files (Windows only)
- Seamless (live) tool changes when Upgrade licenses are applied

V1.134.0001 – Initial Product Release

RELEASE DATE: JULY 2021

- Bug Fixes
 - Stability Improvements
-

Known Issues

- External illumination does not turn ON when running a job created with a previous (non-current) firmware version
- Continuous and Presentation modes are disabled for VS devices when only "Read DPM" or "Read DPM & Barcode" tool is added in flow builder
- Mouse can stop responding on DisplayPort after prolonged use.
 - Resolution: press "Ctrl + Alt + Backspace" to restart HMI
- On FS10, certain hubs cause USB interfaces (both RNDIS and HID) to break on HID Keyboard re-enumeration
 - Resolution: Disconnect and reconnect USB cable.
- Within "Locate Object Plus" tool, the edge contrast image fails to update when tool fails
- Firmware update is failing with "Invalid plugin file" when FW plugin filename has special characters (i.e. space , parentheses, etc)
- Firmware update will fail if memory consumption is already high
- "Image Saving" logic does not take into account "Advanced Pass/Fail Configuration" or local "Disabling" of tool
- Startup job can change when FW Update is performed when a Continuous job is running
- Monitoring device via Aurora for a long time may result in an Aurora restart.
 - Recommended: Use Web HMI for long term job monitoring
- Uninstalling the InstallShield does not always remove all registry entries.
 - Resolution: regedit and manually delete Aurora folder under Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Zebra\
- FS40 jobs may disconnect and fall back to emulator-mode when "Show Images" option is disabled and "Save Images" option is enabled while powered via 24v power supply and using USB-C communication cable.

Components

SW Component	Version
InstallShield	2.0.8000
Aurora™	2.0.8
BSP (xS40/70)	CAAESS00-001-R34

BSP (FS10/xS20)	CAAFFS00-001-R34
Aurora™ HMI	1.0.35

The components are installed in the following folders:

Component	Location
Application	Program Files\Zebra Technologies\Aurora
Job/Configuration Files	Users\Public\Documents\ZebraAurora\xSx0\Jobs
Saved Images	Users\Public\Documents\ZebraAurora\Captures\xSxxxxxx Camera

Minimum PC Requirements

Component	Location
CPU	Intel or AMD 64-bit processor
Random Access Memory Files	4 GB Recommended: 8GB
GPU	GTX 1030, Intel UHD 620 or equivalent
Graphics Memory	2GB Recommended: 4GB
Disk Space	4GB free disk space
Monitor Resolution	1280 x 800 Recommended: 1920 x 1080
Operating System	Windows 10
Internet Connection	Required for software activation

Installation

Aurora™ can be launched from the Windows 10 Start button.

- Start / All Programs / Zebra Scanner / Zebra Aurora