


ZD421

Ribbon Cartridge Desktop Printer



IMPORTANT

Go to zebra.com/zd421c-info and install the driver for your printer.



The driver **MUST** be installed before connecting the printer to the computer, or it will cause complications. If your Microsoft Windows-based computer does not have the driver installed for this printer, download it from zebra.com/zd421c-info and install it before continuing.

After unpacking, make sure you have all items shown below.



Printer



Quick Start Guide



USB Cable





Power Cord



Power Supply

! Labels and the ribbon cartridge are not included.



Slide the release latches (1) to the front to unlock the cover.

Open the printer and remove the packing (1).



Quick Start Guide



Unroll (1) and discard (2) the outer layer of the media roll (3).

Spread the roll holders open (1) and place the roll (2) into the printer.

Verify the roll spins easily on the holder.

Pull the end of the roll past the front edge of the printer.

Press the media under the guides (1).

Align the sensor to the center of the roll for regular labels (1).




Align the sensor to the edge of the roll for marked labels (1).


Insert the ribbon cartridge (1).

Press down until the cartridge clicks into place.

Push down on the front edge of the printer until it locks.



1. Plug the power supply into the printer.
2. Plug the power cable into the power supply.
3. Plug the power cord into an appropriate receptacle.
4. Verify that the power supply lights green.



1. Connect a USB cable to the printer.
2. Connect the other end to your printer.



Press **POWER** (1).



When the printer is ready, the printer status light turns green (1).



Press and hold **PAUSE** (1) + **CANCEL** (2) for two seconds to line up the labels.



Press and hold **FEED** (1) + **CANCEL** (2) for two seconds to print a configuration report.



When the media runs out, the printer status and media status lights turn red (1).



Open the printer and discard the empty roll (1).



Clean the printhead (1) with a cleaning pen (2). Clean from the middle to the outside. Do not use a cleaning pen on the platen.



Zebra Technologies | 3 Overlook Point | Lincolnshire, IL 60069 USA zebra.com
ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. © 2023 Zebra Technologies Corp. and/or its affiliates. All rights reserved.



View user documentation.
zebra.com/zd421c-info

View Quick Answers and Knowledge Base.
zebra.com/knowledge



Need to design a label?
zebra.com/zebradesigner

Join Community Connection of Zebra users and ambassadors.
zebra.com/supportcommunity



Learn about genuine Zebra supplies.
zebra.com/supplies

Contact Zebra about your printer.
zebra.com/contactsupport



Need to manage your printer?
zebra.com/profilemanager

Need to secure your printer?
zebra.com/printsecure



Learn about product patent information.
ip.zebra.com



When the ribbon runs out, the printer status and ribbon status lights turn red (1).



Open the printer and discard the empty cartridge (1).