

MC65 OPERATING SYSTEM BSP 72.44.1001 - HOTFIX CFE 1.04 RELEASE NOTES

INTRODUCTION

HotFix CFE (Cumulative Fixes from Engineering) Package includes multiple SPR Hotfixes contained into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR Hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologie's HotFix Package Policy.

DESCRIPTION

The content and related Hot fixes that are included in this HotFix CFE_MC65_72441001_WM_EN_v010400_v1_0_e_NB.cab / CFE_MC65_72441001_WM_EN_v010400_v1_0_e_WB.cab is as follows.

SPR No	Synopsis
27532	Battery drains while it is in cradle and does not critically suspend
27437	Device reboots instead of resuming when power key is pressed.
27308	Device is running out of registry handles. The CFE fixes the battery driver which opens registry key but not closing the registry key.
26839	Battery drains while it is in cradle and does not critically suspend.

PACKAGE DETAILS

CFE_MC65_72441001_WM_EN_v010400_v1_0_e_WB.cab (CFE package with Warm boot)

CFE_MC65_72441001_WM_EN_v010400_v1_0_e_NB.cab (CFE package without Warm boot)



DEVICE COMPATIBILITY

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
MC65	WM 6.5	v72.44.1001

INSTALLATION REQUIREMENTS

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM Set up

INSTALLATION INSTRUCTIONS

For Normal installation of the PATCH:

- Windows Mobile Device Center (For Windows Desktops) Installation Instructions:

1. Copy "CFE_MC65_72441001_WM_EN_v010400_v1_0_e_WB.cab" file to the Application folder on the device.

2. Deploy the solution by tapping on the "CFE_MC65_72441001_WM_EN_v010400_v1_0_e_WB.cab" file.

3. After successful deployment of the "CFE_MC65_72441001_WM_EN_v010400_v1_0_e_WB.cab" file device will do an automatic warm boot.

- SD Cards / Micro SD cards Installation Instructions:

1. Copy "CFE_MC65_72441001_WM_EN_v010400_v1_0_e_WB.cab" file to the SD card.



2. Deploy the solution by tapping on the
"CFE_MC65_72441001_WM_EN_v010400_v1_0_e_WB.cab"

3. After successful deployment of the
"CFE_MC65_72441001_WM_EN_v010400_v1_0_e_WB.cab" file device will do an
automatic warm boot.

For MSP or REMOTE installation of the PATCH:

1. Set up MDM (MSP, Soti, Airwatch, etc..) to send
"CFE_MC65_72441001_WM_EN_v010400_v1_0_e_NB.cab" file to the application
folder of the device.

2. To deploy the solution, setup in MDM to install the cab file
"CFE_MC65_72441001_WM_EN_v010400_v1_0_e_NB.cab" file.

3. Changes will take effect after a manual reboot of the terminal or if MDM reboots
device.

RELEASE DATE

September, 2015