

MC67ND OPERATING SYSTEM BSP

04.56.13 - HOTFIX CFE 01.01.00

RELEASE NOTES

INTRODUCTION

HotFix CFE (Cumulative Fixes from Engineering) Package includes multiple SPR Hotfixes contained into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies HotFix Package Policy.

DESCRIPTION

The content and related Hot fixes that are included in this HotFix CFE_MC67_ND_045613_WM_EN_v010100_e_WB.cab /CFE_MC67_ND_045613_WM_EN_v010100_e_NB.cab is as follows.

SPR No	Synopsis
27938	Custom camera setting not persistent over warmboot. This CFE hotfix includes a new camera driver that will persistent the custom camera settings like focus mode, ISO, scene mode, flash mode and white balance mode, on device warmboot.

PACKAGE DETAILS

CFE_MC67_ND_045613_WM_EN_v010100_e_WB.cab (CFE package with Warm boot)

CFE_MC67_ND_045613_WM_EN_v010100_e_NB.cab (CFE package without Warm boot)

DEVICE COMPATIBILITY

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
MC67ND	WM 6.5	v04.56.13

INSTALLATION REQUIREMENTS

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM set up

INSTALLATION INSTRUCTIONS

For Normal installation of the PATCH:

Windows Mobile Device Center (For Windows Desktops) Installation Instructions:

1. Copy "CFE_MC67_ND_045613_WM_EN_v010100_e_WB.cab" file to the Application folder on the device.
2. Deploy the solution by tapping on the "CFE_MC67_ND_045613_WM_EN_v010100_e_WB.cab" file.
3. After successful deployment of the "CFE_MC67_ND_045613_WM_EN_v010100_e_WB.cab" file, device will do an automatic warm boot.
4. Do manual warmboot.

SD Cards / Micro SD cards Installation Instructions:



1. Copy "CFE_MC67_ND_045613_WM_EN_v010100_e_WB.cab" file to the SD card.
2. Deploy the solution by tapping on the "CFE_MC67_ND_045613_WM_EN_v010100_e_WB.cab"
3. After successful deployment of the "CFE_MC67_ND_045613_WM_EN_v010100_e_WB.cab" file, device will do an automatic warm boot.
4. Do manual warmboot.

For MSP or REMOTE installation of the PATCH:

1. Set up MDM (MSP, Soti, Airwatch, etc..) to send "CFE_MC67_ND_045613_WM_EN_v010100_e_NB.cab" file to the application folder of the device.
2. To deploy the solution, setup in MDM to install the cab file "CFE_MC67_ND_045613_WM_EN_v010100_e_NB.cab" file.
3. Changes will take effect after a manual reboot of the terminal or if MDM reboots device.
4. Do manual warmboot.

RELEASE DATE

February, 2016