



MC9100 OPERATING SYSTEM BSP V04.47.12 - HOTFIX CFE V01.01.00 RELEASE NOTES

INTRODUCTION

HotFix CFE (Cumulative Fixes from Engineering) Package contains multiple SPR Hotfixes into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies HotFix Package Policy. [HotFix Support Policy](#)

DESCRIPTION

CFE package "CFE_MC91_WM_044712_EN_v010100_e_WB.cab / CFE_MC91_WM_044712_EN_v010100_e_NB.cab" file includes the following HotFixes:

SPR NO	Synopsis
28804	<p>On pairing MC9190 unit with RS507 Bluetooth scanner, when barcodes are scanned quickly using WScanWedge application, after sometime BT scanner RS507 beam goes OFF and doesn't come back.</p> <p>To fix this issue, "UnifiedScanPDD.dll" of the scanner driver has been modified.</p>

PACKAGE DETAILS

CFE_MC91_WM_044712_EN_v010100_e_WB.cab (CFE package with auto Warm boot)

CFE_MC91_WM_044712_EN_v010100_e_NB.cab (CFE package without auto Warm boot)

DEVICE COMPATIBILITY

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
MC9190	WEH6.5	v04.47.12

INSTALLATION REQUIREMENTS

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM set up

INSTALLATION INSTRUCTIONS

For Normal installation of the PATCH:

- Windows Mobile Device Center (For Windows Desktops) Installation Instructions:

1. Copy "CFE_MC91_WM_044712_EN_v010100_e_WB.cab" file to the Application folder on the device.
2. Deploy the solution by tapping on the "CFE_MC91_WM_044712_EN_v010100_e_WB.cab" file.
3. Change will take effect after manual reboot of the terminal is done.

- SD Cards / Micro SD cards Installation Instructions:

1. Copy "CFE_MC91_WM_044712_EN_v010100_e_WB.cab" file to the SD card.
2. Deploy the solution by tapping on the "CFE_MC91_WM_044712_EN_v010100_e_WB.cab"
3. Change will take effect after manual reboot of the terminal is done.

For MSP or REMOTE installation of the PATCH:

1. Set up MDM (MSP, Soti, Airwatch, etc..) to send "CFE_MC91_WM_044712_EN_v010100_e_NB.cab"• file to the application folder of the device.

2. To deploy the solution, setup in MDM to install the cab file “CFE_MC91_WM_044712_EN_v010100_e_NB.cab” file.
3. Changes will take effect after a manual reboot of the terminal or if MDM reboots device.

RELEASE DATE

April 5, 2016