



# MC9100 OPERATING SYSTEM BSP V04.47.12 - HOTFIX CFE V01.02.00 RELEASE NOTES

## INTRODUCTION

HotFix CFE (Cumulative Fixes from Engineering) Package contains multiple SPR Hotfixes into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies HotFix Package Policy. [HotFix Support Policy](#)

## DESCRIPTION

CFE package

CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_NB.cab/CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_WB.cab file includes the following HotFixes:

SPR No	Synopsis
30013	Device is unable to read DataMatrix from 1m distance.
28804	On pairing MC9190 unit with RS507 Bluetooth scanner, when barcodes are scanned quickly using WScanWedge application, after sometime BT scanner RS507 beam goes OFF and doesn't come back. To fix this issue, "UnifiedScanPDD.dll" of the scanner driver has been modified.

This HotFix CFE package

CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_NB.cab/CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_WB.cab obsoletes the following HotFix CFEs:

HotFix CFE version	Product
CFE_MC91_WM_044712_EN_v010100_e_WB.cab CFE_MC91_WM_044712_EN_v010100_e_NB.cab	MC9190



*Note: Latest CFE package includes previous CFE package hot fixes and new SPR hotfix.*

## PACKAGE DETAILS

CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_NB.cab (CFE package without Warm boot)

CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_WB.cab (CFE package with Warm boot)

## DEVICE COMPATIBILITY

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
MC9190	WM 6.5	04.47.12

## INSTALLATION REQUIREMENTS

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM set up

## INSTALLATION INSTRUCTIONS

### For Normal installation of the PATCH:

- Windows Mobile Device Center (For Windows Desktops) Installation Instructions:
  1. Copy "CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_WB.cab" file to the Application folder on the device.

2. Deploy the solution by tapping on the "CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_WB.cab" file.

3. After successful deployment of the "CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_WB.cab" file, device will do an automatic warm boot.

- SD Cards / Micro SD cards Installation Instructions:
  1. Copy "CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_WB.cab" file to the SD card.

2. Deploy the solution by tapping on the "CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_WB.cab"

3. After successful deployment of the "CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_WB.cab" file, device will do an automatic warm boot.

## FOR MSP OR REMOTE INSTALLATION OF THE PATCH:

1. Set up MDM (MSP, Soti, Airwatch, etc..) to send "CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_NB.cab" file to the application folder of the device.
2. To deploy the solution, setup in MDM to install the cab file "CFE\_MC91\_WM\_044712\_EN\_v010200\_e\_NB.cab" file.
3. Changes will take effect after a manual reboot of the terminal or if MDM reboots device.

## PART NUMBER AND RELEASE DATE

September, 2016