

Installation Instruction for ST6082 Rubber Boot

I. Installation of the ST6082 Yellow Rubber Boot for the Expansion Back.

STEP 1.
INSERT HANDHELD THROUGH
OPENING IN THE RUBBER BOOT
AS SHOWN IN FIGURE A.



Figure A



Figure B

STEP 2.
SECURELY FIT THE FRONT
END OF THE HANDHELD IN
THE END OF RUBBER BOOT.
SEE FIGURE B.

Continued on other side... →

STEP 3.
 FIRMLY PULL BOTTOM CORNERS OF RUBBER BOOT (ONE AT A TIME WORKS BEST) AROUND THE END OF THE HANDHELD UNTIL SECURELY ENCLOSED. AS SHOWN IN FIGURES C AND D.



Figure C



Figure D



Figure E

STEP 4.
 FIGURE E SHOWS THE COMPLETED ASSEMBLY OF THE RUBBER BOOT.

Appendix A: Support Services

For technical support, please visit the Support section of our community Ingenuity Working: <http://community.pSION.com/support>