

# Installation Instruction for ST6083 Rubber Boot

## I. Installation of the ST6083 Grey Rubber Boot for the Expansion Back.

**STEP 1.**  
INSERT HANDHELD THROUGH  
OPENING IN THE RUBBER BOOT  
AS SHOWN IN FIGURE A.




Figure A



Figure B

**STEP 2.**  
SECURELY FIT THE FRONT  
END OF THE HANDHELD IN  
THE END OF RUBBER BOOT.  
SEE FIGURE B.

*Continued on other side...* →

**STEP 3.**  
 FIRMLY PULL BOTTOM CORNERS OF RUBBER BOOT (ONE AT A TIME WORKS BEST) AROUND THE END OF THE HANDHELD UNTIL SECURELY ENCLOSED. AS SHOWN IN FIGURES C AND D.



Figure C



Figure D



**STEP 4.**  
 FIGURE E SHOWS THE COMPLETED ASSEMBLY OF THE RUBBER BOOT.

## Appendix A: Support Services

For technical support, please visit the Support section of our community Ingenuity Working: <http://community.pSION.com/support>