

Installation Instruction Workabout Pro S Rubber Case

1. Installation

- Figure A: Insert Workabout Pro S handheld through opening of rubber boot. Securely fitting the front end of the Workabout Pro S handheld in the end of the rubber boot.
- Figure B & C: Firmly pull bottom corners of rubber boot (one at a time works best) around the end of the Workabout Pro S handheld until securely enclosed.
- Figure D: Complete.



Figure A



Figure B



Figure C



Figure D

COMPANY HEADQUARTERS AND CANADIAN SERVICE CENTRE

PSION Inc.
 2100 Meadowvale Boulevard, Mississauga
 Ontario, Canada L5N 7J9
 Tel: +1 905 813 9900
 Fax: +1 905 812 6300
 E-mail: salescdn@psion.com
www.pSION.com
www.ingenuityworking.com