Release Notes - WT41N0 CE 7.0 - BSP v03.54.02 - HotFix CFE v01.03.00 Package

Introduction

HotFix CFE (Cumulative Fixes from Engineering) Package includes multiple SPR Hotfixes contained into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies HotFix Package Policy. Click here to view HotFix Package Policy. HotFix Support Policy

Description

The content and related Hot fixes that are included in this HotFix CFE_WT41_CE_035402_EN_v010300_e_WB.cab / CFE_WT41_CE_035402_EN_v010300_e_NB.cab is as follows.

SPR No	Synopsis
27572	Audio fails to get routed to Wide Band BT headset when connected to device
25169	Display orientation issue
27525	Unable to Pair RS507 using Telnet Client

This HotFix CFE package CFE_MC67_NA_034639_WM_EN_v010400_e_WB / CFE_MC67_NA_034639_WM_EN_v010400_e_NB.cab obsoletes the following HotFix CFEs:

HotFix CFE version	Product
CFE_WT41_CE_035402_EN_v010200_e_NB.cab CFE_WT41_CE_035402_EN_v010200_e_WB.cab	WT41N0
CFE_WT41_CE_035402_EN_v010100_e.cab	WT41N0

Note: Latest CFE package includes previous CFE package hot fixes and new SPR hotfix.

Package Details

CFE_WT41_CE_035402_EN_v010300_e_WB.cab (CFE package with Warm boot)

CFE_WT41_CE_035402_EN_v010300_e_NB.cab (CFE package without Warm boot)

Device Compatibility

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
WT41N0	CE 7.0	v03.54.02

Installation Requirements

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM set up

Installation Instructions

For Normal installation of the PATCH:

- Windows Mobile Device Center (For Windows Desktops) Installation Instructions:

    1. Copy "CFE_WT41_CE_035402_EN_v010300_e_WB.cab" file to the Application folder on the device.

    2. Deploy the solution by tapping on the "CFE_WT41_CE_035402_EN_v010300_e_WB.cab" file.

    3. After successful deployment of the "CFE_WT41_CE_035402_EN_v010300_e_WB.cab" file, device will do an automatic warm boot.

- SD Cards / Micro SD cards Installation Instructions:

    1. Copy "CFE_WT41_CE_035402_EN_v010300_e_WB.cab" file to the SD card.

    2. Deploy the solution by tapping on the "CFE_WT41_CE_035402_EN_v010300_e_WB.cab"

    3. After successful deployment of the "CFE_WT41_CE_035402_EN_v010300_e_WB.cab" file, device will do an automatic warm boot.

For MSP or REMOTE installation of the PATCH:

    1. Set up MDM (MSP, Soti, Airwatch, etc..) to send " CFE_WT41_CE_035402_EN_v010300_e_NB.cab" file to the application folder of the device.

    2. To deploy the solution, setup in MDM to install the cab file " CFE_WT41_CE_035402_EN_v010300_e_NB.cab" file.

    3. Changes will take effect after a manual reboot of the terminal or if MDM reboots device.

Release Date

May, 2015