

- [Introduction](#)
- [Description](#)
- [Contents](#)
- [Device Compatibility](#)
- [Installation Requirements](#)
- [Installation Instructions](#)
- [Release Date](#)

## Introduction

HotFix CFE (Cumulative Fixes from Engineering) Package includes multiple SPR Hotfixes contained into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR Hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies HotFix Package Policy. Click here to view HotFix Package Policy. [HotFix Support Policy](#)

## Description

The content and related Hot fixes that are included in this HotFix CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_WB.cab / CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_NB.cab is as follows.

SPR No	Synopsis
27607	On pairing WT41N0 unit with RS507 Bluetooth scanner, when barcode are scanned continuously, sometimes scanner beam goes off for 3 sec. Scanner beam comes back after 3 sec and it starts scanning barcodes again as usual. To fix this issue, the "UnifiedScanPDD.dll" of the scanner driver has been modified.
27572	Audio fails to get routed to Wide Band BT headset when connected to device.
27525	Unable to Pair RS507 using Telnet Client.
25169	Display orientation issue.

## Package Details

CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_WB.cab (CFE package with automatic Warm boot)

CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_NB.cab (CFE package without Warm boot)

## Device Compatibility

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
WT41N0	CE 7.0	v03.54.02

## Installation Requirements

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM Set up

## Installation Instructions

### For Normal installation of the PATCH:

- Windows Mobile Device Center (For Windows Desktops) Installation Instructions:
  - Copy "CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_WB.cab" file to the Application folder on the device.
  - Deploy the solution by tapping on the "CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_WB.cab" file.
  - After successful deployment of the "CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_WB.cab" file device will do an automatic warm boot.
- SD Cards / Micro SD cards Installation Instructions:
  - Copy "CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_WB.cab" file to the SD card.
  - Deploy the solution by tapping on the "CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_WB.cab" file.
  - After successful deployment of the "CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_WB.cab" file device will do an automatic warm boot.

### For MSP or REMOTE installation of the PATCH:

- Set up MDM (MSP, Soti, Airwatch, etc..) to send "CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_NB.cab" file to the application folder of the device.
- To deploy the solution, setup in MDM to install the cab file "CFE\_WT41N0\_CE\_035402\_EN\_v010400\_e\_NB.cab" file.
- Changes will take effect after a manual reboot of the terminal or if MDM reboots device.

## Release Date

October 28,2015