
Release Notes - MC36 Android KK - BSP v2.46 - HotFix CFE v00.01 Package

[Introduction](#)

[Component Description and Version](#)

[Package Details](#)

[Device Compatibility](#)

[Installation Requirements](#)

[Installation Instructions](#)

[Release Date](#)

Introduction

HotFix CFE (Cumulative Fixes from Engineering) Package contains multiple SPR Hotfixes into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies HotFix Package Policy. Click here to view [HotFix Package Policy](#).

Component Description and Version

1. Kit Kat 4.4.2
2. Kernel v2.4.6
3. Scanning Framework 1.0.1
4. WiFi FW 7.a3
5. NFC NCORE_1.30_15081101
6. BT 8a00
7. TP FW 5509
8. Modem MOLY.WR8.W1315.MD.WG.MP.V62.F1.P2

Fixes Included:

The CFE package **CFE-MC36N0-K-XX-24600-X-00-01**.zip file includes the following HotFixes:

- SPR31253 - Resolved the Intermittent connecting issue to BT QPOS system
- SPR32544 - Resolved an issue wherein NFC Scanning was disabled when application associate with Barcode Scanning function
- SPR32605 - Resolved an issue that unable to view new folder/file created when connecting MC36 via USB on PC
- SPR32750 - Resolved an issue wherein alphabets hard key input was not changing when clicking the same button few times in the browser

Package Details

CFE-MC36N0-K-XX-24600-X-00-01.zip

Device Compatibility

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
MC36	Android KK 4.4.2	v2.46

Installation Requirements

This SW is intended for the MC36 device (Both 1D and 2D SKU)

Installation Instructions

1. Connect MC36 Android unit to PC over USB cable
2. Press and hold <Power> Key for 2 seconds and select reboot in the poweroff pop-up menu
3. Press and hold <Volume_Up>key as soon as the device starts rebooting
4. When Android reboot logo appears on the screen release <Volume_Up> key
5. Wait until recovery menu appear.

6. Use <Volume_Up> and <Volume_Down> keys to navigate items.
7. Use <Enter> key to select menu item.
8. Select "apply update from adb".
9. On PC side, go to the directory where you have the **CFE-MC36N0-K-XX-24600-X-00-01.zip**
10. Run "adb sideload **CFE-MC36N0-K-XX-24600-X-00-01.zip**" in command line console.
11. When update is complete, select "reboot system now" on device to reboot

Note: battery must have at least 30% charge for the update to proceed.

Release Date

January 2018