

MC92 WM 6.5 STANDARD - BSP V10.55.11 - HOTFIX CFE V01.01.00 PACKAGE RELEASE NOTES

MC9200 Operating System for Standard SKUs

INTRODUCTION

HotFix CFE (Cumulative Fixes from Engineering) Package contains multiple SPR Hotfixes into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies HotFix Package Policy.

HotFix Support Policy

DESCRIPTION

CFE package

CFE_MC92_WM_LC_105511_EN_v010100_e_WB.cab/CFE_MC92_WM_LC_105511_EN_v010100_e_NB.cab file includes the following HotFixes:

SPR NO	Synopsis
29433	Ethernet connection does not reestablish when device removed and put back into Ethernet cradle. Warm boot required for reconnect.

PACKAGE DETAILS

CFE_MC92_WM_LC_105511_EN_v010100_e_WB.cab (CFE package with auto Warm boot) CFE_MC92_WM_LC_105511_EN_v010100_e_NB.cab (CFE package without auto Warm boot)

DEVICE COMPATIBILITY

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
MC92N0 Standard	WEH 6.5	v10.55.11

INSTALLATION REQUIREMENTS

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM Set up

INSTALLATION INSTRUCTIONS

For Normal installation of the PATCH:

- Windows Mobile Device Center Installation Instructions:
 1. Copy 'CFE_MC92_WM_LC_105511_EN_v010100_e_WB.cab' file to the Application folder on the device.
 2. Deploy the solution by tapping on the 'CFE_MC92_WM_LC_105511_EN_v010100_e_WB.cab' file.
 3. After successful deployment of the 'CFE_MC92_WM_LC_105511_EN_v010100_e_WB.cab' file, device will do an automatic warm boot.
- SD Cards / Micro SD cards Installation Instructions:
 1. Copy 'CFE_MC92_WM_LC_105511_EN_v010100_e_WB.cab' file to the SD card.
 2. Deploy the solution by tapping on the 'CFE_MC92_WM_LC_105511_EN_v010100_e_WB.cab'
 3. After successful deployment of the

'CFE_MC92_WM_LC_105511_EN_v010100_e_WB.cab' file, device will do an automatic warm boot.

For MSP or REMOTE installation of the PATCH:

- 1. Set up MDM (MSP, Soti, Airwatch, etc..) to send 'CFE_MC92_WM_LC_105511_EN_v010100_e_NB.cab' file to the application folder of the device.**
- 2. To deploy the solution, setup in MDM to install the cab file 'CFE_MC92_WM_LC_105511_EN_v010100_e_NB.cab' file.**
- 3. Changes will take effect after a manual reboot of the terminal or if MDM reboots device.**

RELEASE DATE

May, 2016