

---

# Release Notes – MC92N0 CE 7.0 - German BSP v06.57.22 - Hotfix CFE v01.03.00 Package

---

[Introduction](#)

[Description](#)

[Package Details](#)

[Device Compatibility](#)

[Installation Requirements](#)

[Installation Instructions](#)

[Release Date](#)

## Introduction

---

Hotfix CFE (Cumulative Fixes from Engineering) Package contains multiple SPR Hotfixes into a single package. The Hotfix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision.

Hotfix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies Hotfix Package Policy. Click here to view [Hotfix Package Policy](#).

## Description

---

CFE package CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_WB.cab / CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_NB.cab file includes the following Hotfixes:

SPR No	Synopsis
34608	Laser scanner beam stays for few seconds even after trigger button released
33821/32595	RDP Dialog screens are going out of device screen
33347	SIP keyboard always shows English character in localized OS

This Hotfix CFE package CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_WB.cab / CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_NB.cab obsoletes the following Hotfix CFEs:

Hotfix CFE version
CFE_MC92_CE_065722_DE_v010200_e_WB.cab CFE_MC92_CE_065722_DE_v010200_e_NB.cab

*Note: Latest CFE package includes previous CFE package hot fixes and new SPR hot fix.*

## Package Details

---

CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_WB.cab (CFE package with auto Warm boot)

CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_NB.cab (CFE package without auto Warm boot)

## Device Compatibility

---

This Hotfix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
MC92N0	CE 7.0	v06.57.22

**Note: This release is applicable for German OS only.**

## Installation Requirements

---

The Hotfix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM set up

## Installation Instructions

---

### For Normal installation of the PATCH:

- **Windows Mobile Device Center (For Windows Desktops) Installation Instructions:**
  1. Copy "CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_WB.cab" file to the Application folder on the device.
  2. Deploy the solution by tapping on the "CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_WB.cab" file.
  3. After successful deployment of the "CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_WB.cab" file, device will do an automatic warm boot.
- **SD Cards / Micro SD cards Installation Instructions:**
  1. Copy "CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_WB.cab" file to the SD card.

2. Deploy the solution by tapping on the "CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_WB.cab".
3. After successful deployment of the "CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_WB.cab" file, device will do an automatic warm boot.

### **For MSP or REMOTE installation of the PATCH:**

1. Set up MDM (MSP, Soti, Airwatch, etc..) to send "CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_NB.cab" file to the application folder of the device.
2. To deploy the solution, setup in MDM to install the cab file "CFE\_MC92\_CE\_065722\_DE\_v010300\_e\_NB.cab" file.
3. Changes will take effect after a manual reboot of the terminal or if MDM reboots device.

## **Release Date**

---

May 2018