Release Notes - MC9596 WM 6.5 - BSP v06.47.12 - HotFix CFE v01.01.00 Package

Introduction

Description

Package Details

Device Compatibility

Installation Requirements

Installation Instructions

Release Date

Introduction

HotFix CFE (Cumulative Fixes from Engineering) Package includes multiple SPR Hotfixes contained into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows ZebraTechnologies HotFix Package Policy. Click here to view HotFix Package Policy. HotFix Support Policy

Description

The content and related Hotfix included in this HotFix CFE_MC9596_WM_064712_EN_v010100_e_WB.cab/CFE_MC9596_WM_064712_EN_v010100_e_NB.cab is as follows.

SPR No	Synopsis
28401	Device Fusion/WIFI adapter Keep on resetting after connect to WIFI and placed in cradle.
	This fix also corrects the SPR 25317 and SPR 26402.

Note: For SPR 28401

- This is a SDIO patch and needs to be installed with Latest Fusion(37R or onwards).
- Prior to installation, ensure that you are currently running an approved version of the Operating System
 from the table above. Otherwise, visit https://portal.motorolasolutions.com/Support/US-EN and load the
 correct DCP for your product. This installation contains DHCP.dll which includes DHCP client having
 fixes for few SPRs. This is required if this cab is installed on any older OEM version.

Package Details

CFE_MC9596_WM_064712_EN_v010100_e_NB.cab (CFE package without Warm boot)
CFE_MC9596_WM_064712_EN_v010100_e_NB.cab (CFE package with Warm boot)

Device Compatibility

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
MC9596	WM6.5	v06.47.12

Installation Requirements

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM set up

Installation Instructions

- Windows Mobile Device Center (For Windows Desktops) Installation Instructions:
 - 1. Copy "CFE_MC9596_WM_064712_EN_v010100_e_WB.cab" file to the Application folder on the device.
 - 2. Deploy the solution by tapping on the "CFE_MC9596_WM_064712_EN_v010100_e_WB.cab" file.
 - 3. After successful deployment of the "CFE_MC9596_WM_064712_EN_v010100_e_WB.cab" file, device will do an automatic warm boot.
- SD Cards / Micro SD cards Installation Instructions:
 - 1. Copy "CFE MC9596 WM 064712 EN v010100 e WB.cab" file to the SD card.
 - 2. Deploy the solution by tapping on the "CFE MC9596 WM 064712 EN v010100 e WB.cab"
 - 3. After successful deployment of the "CFE_MC9596_WM_064712_EN_v010100_e_WB.cab" file, device will do an automatic warm boot.

For MSP or REMOTE installation of the PATCH:

- Set up MDM (MSP, Soti, Airwatch, etc..) to send "CFE_MC9596_WM_064712_EN_v010100_e_NB.cab" file to the application folder of the device.
- 2. To deploy the solution, setup in MDM to install the cab file "CFE MC9596 WM 064712 EN v010100 e NB.cab" file.
- 3. Changes will take effect after a manual reboot of the terminal or if MDM reboots device.

Release Date

January, 2016