Installation Instructions:

- 1. Download the package, unzip the file, and place it onto a storage device.
- 2. Ensure that the main battery is well charged, or the device is in a powered docking station.
- 3. Insert the storage device.
- 4. Boot the device into BooSt by pressing and holding the Blue + Enter + Scan button for 7 seconds.
- 5. The image should run, and load the appropriate files. Do not remove the storage device or power until the upgrade process has been successfully completed.

For more information on the Transitional BooSt for terminals with current BooSt versions 2.0 (H088) – 3.0 (B199) please see: **Transitional BooSt**