

# VC70N0 OPERATING SYSTEM BSP V04.54.02 - HOTFIX CFE V01.00.00 RELEASE NOTES

## INTRODUCTION

SPR 27858 reported an issue wherein the VC70 device does not pair with RS507 when Telnet Client is used to pair the device.

## DESCRIPTION

Release Notes - VC70 CE 7.0 - BSP v04.54.02 - When Telnet Client Is Used To Pair Device With RS507, The Device Does not Pair - SPR 27858

The Provided Packages resolve the VC70 pairing issue with RS507 using Telnet Client.

*Note:* This fix works with latest Telnet client **WLTE\_MOT\_VC7000\_CE7\_7\_3\_196\_AS.exe**. This Telnet version is available to download from [www.wavelink.com](http://www.wavelink.com)

## CONTENTS

SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_WB.cab (HotFix package with Warm boot)

SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_NB.cab(HotFix package without Warm boot)

## DEVICE COMPATIBILITY

This HotFix Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
VC70N0	CE 7.0	v04.54.02



## INSTALLATION REQUIREMENTS

The HotFix cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools.

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM Set up

## INSTALLATION INSTRUCTIONS

### **For Normal installation of the PATCH:**

- Windows Mobile Device Center (For Windows Desktops) Installation Instructions:

1. Copy "SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_WB.cab" file to the Application folder on the device.
2. Deploy the solution by tapping on the "SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_WB.cab" file.
3. After successful deployment of the "SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_WB.cab" file device will do an automatic warm boot.

- SD Cards / Micro SD cards Installation Instructions:

1. Copy "SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_WB.cab" file to the SD card.
2. Deploy the solution by tapping on the "SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_WB.cab"
3. After successful deployment of the "SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_WB.cab" file device will do an automatic warm boot.

### **For MSP or REMOTE installation of the PATCH:**

1. Set up MDM (MSP, Soti, Airwatch, etc..) to send "SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_NB.cab" file to the application folder of the device.
2. To deploy the solution, setup in MDM to install the cab file "SPR27858\_VC70\_C70\_en\_045402\_v1\_0\_NB.cab" file.

3. Changes will take effect after a manual reboot of the terminal or if MDM reboots device.

## RELEASE DATE

July 2015