

# Firmware version 01.57.34 release for MK3100 Series Micro Kiosk

---

## Contents

- [Description](#)
  - [Device Compatibility](#)
  - [Release Notes](#)
  - [Components](#)
  - [Installation](#)
  - [Notes](#)
- 

## Description

This firmware update for MK3100 is provided for updating firmware within MK3100 series Micro Kiosks.

---

## Device Compatibility

MK3100

---

## Release Notes

### Version 01.57.34

1. Updated to FUSION\_X\_2.03.0.0.018R\_MPA3\_CE70.
- 

## Components

Component	Location
3c00c70BenSD105734.zip	A collection of all partition image files for MK3100: SDcard complete OS update
3c00c70BenHX105734.zip	A collection of all partition image files for MK3100: manual update

---

## Installation

1. Un-zip the “3c00c70BenSD10xxxx.zip” file and copy these files to a FAT32 formatted microSD card.
  2. Now place the card into the microSD slot on the MK3100,
  3. While holding down the first and third key on the keypad,
  4. Plug in the power cable.
  5. The monitor menu will appear, now you can let go of the keys.
  6. To navigate the menus use:
  7. Key 1 = UP, Key 2 = DOWN, Key 3 = ENTER, Key 4 = ESCAPE
  8. Select “download from sd card”, hit enter
  9. Select the “3C0AllLoad.mcf” file, hit enter
  10. Approximately 5 minutes, the OS is fully loaded, power cycle to re-start the system.
- 

## Notes

**MK3100 does not contain a radio module.**

---