

Installation Instructions for Industrial Printers

Read these instructions thoroughly before installing this kit.

Parts List

Before proceeding, verify that your kit contains the following items. To reorder specific parts, navigate to zebra.com/parts, and select your printer model.

Antenna, external Wi-Fi, tri-band, RSMA		Qty 1
---	--	-------

Replace the Wi-Fi Antenna

1. Unscrew the Wi-Fi antenna.
2. Screw the new antenna onto the RF connector (1) that extends from the back of the Wi-Fi card.

