


19-KEY MECHANICAL KEY- OPERATING INSTRUCTIONS



© 2015 ZIH Corp.

Zebra reserves the right to make changes to any product to improve reliability, function, or design.

Zebra does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or by implication, estoppel, or otherwise under any patent right or patent, covering or relating to any combination, system, apparatus, machine, material, method, or process in which Zebra products might be used. An implied license exists only for equipment, circuits, and subsystems contained in Zebra products.

Zebra and the stylized Zebra head are trademarks of ZIH Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. ©2015 ZIH Corp and/or its affiliates. All rights reserved.

Warranty

For the complete Zebra hardware product warranty statement, go to:
<http://www.zebra.com/warranty>.

Introduction





This guide provides keypad operating information for the MC3000 mobile computer with the 19-key mechanical keypad. All other operating instructions are provided in the *MC3000 User Guide*, p/n 72-E-68899-xx, and the *MC3000 Integrator Guide*, p/n 72E-68900-xx.

Turning the Mobile Computer On and Off





Simultaneously press the  and  keys to turn the mobile computer on and off.

Booting the Mobile Computer

To perform a warm boot:








1. Press and hold the  and  keys and then press the  and  keys.
2. As soon as the mobile computer starts to perform a warm boot release the keys.

To perform a cold boot:

1. Press and hold the  and  keys and then press the  and  keys.
2. Release the keys. The mobile computer performs a cold boot.










Keypad Description








The table below lists the default functions of each key. The functionality of the keys can be re-mapped, see [Keypad Mapping on page 5](#).




Key	Description
Menu 	Produces the lower case alphabetic f. Turns the mobile computer on and off when simultaneously pressed with the down arrow key. See Booting the Mobile Computer on page 3 for warm and cold boot procedures.
GoTo 	Produces the lower case alphabetic e.
Alphabetic 	Produces the lower case alphabetic l, d and p characters.
Numeric 	Produces numerics 0 through 9.
C 	Produces a backspace.
Scroll Up and Down 	Moves up and down from one item to another. Increases/decreases specified values.
ENTER 	ENTER key executes a selected item or function.

Keypad Mapping

The 19-key mechanical keypad has the following keypad mapping.

Key	Default State	VK Code (Decimal)	ASCII Value (Decimal)
Menu 	f	70	102
GoTo 	e	69	101
L 	l	76	108
D 	d	68	100
P 	p	80	112
1 	1	49	49
2 	2	50	50
3 	3	51	51
4 	4	52	52

Key	Default State	VK Code (Decimal)	ASCII Value (Decimal)
5 	5	53	53
6 	6	54	54
7 	7	55	55
8 	8	56	56
9 	9	57	57
0 	0	48	48
C 	Backspace	8	8

Key	Default State	VK Code (Decimal)	ASCII Value (Decimal)
ENTER 	Enter	13	13
Up Arrow 	Up	38	-
Down Arrow 	Down	40	-

Service Information

Before using the device, it must be configured to operate in your facility's network and run applications.

If you have a problem running the device or using the equipment, contact your facility's Technical or Systems Support. If there is a problem with the equipment, they will contact the Zebra Customer Interactive Center at:

<http://www.zebra.com/support>.

For the latest version of this guide go to: <http://www.zebra.com/support>.



Zebra Technologies Corporation

Lincolnshire, IL U.S.A

<http://www.zebra.com>

Zebra and the stylized Zebra head are trademarks of ZIH Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners.

©2015 ZIH Corp and/or its affiliates. All rights reserved.



72-94716-02 Rev A - April 2015