


Four-Slot Battery Charger Shim Installation Instructions



CAUTION The shim must be used when charging MC70 batteries.

Before charging an MC70 battery, you must first install the MC70 Battery Shim into the battery well. When charging other batteries, you must remove the shim.



72-76157-03 Revision A - March 2015

Zebra Technologies Corporation
Lincolnshire, IL, USA