



ZD510



1



www.zebra.com/setup



Download and Install Zebra Setup Utilities
Includes Windows Printer Driver Files

2



Setup Your Printer

<http://www.zebra.com/zd510-info>




Printed In China



P1099649-001


3

Connect power cord





4

Connect power and interface



5


Connect to AC and power ON



115 VAC



230 VAC




6



Register For Support

<http://www.zebra.com/register>


Load Media



Operation



= Ready




Eject

Pause/Feed




= Media Low




=



= Media Out



Special Conditions



= Preparing to Print



= 2 Blinks = Paused




= WiFi Option Connected, Good Signal




= WiFi Option Connected, Weak Signal

If Cartridge is manually ejected

Don't Pull




Cut



See User Guide for other conditions

<http://www.zebra.com/zd510-info>

Learn About Genuine Zebra Supplies



<http://www.zebra.com/supplies>



www.zebra.com/zd510-info