


MC919Z


Quick Start Guide

<http://www.zebra.com/mc919Z> See User Guide for more information


BATTERY INSERTION




Front View





Battery Removal




Stylus Removal



SNAP-ON ACCESSORY INSTALLATION




Cable Adapter Module




Magnetic Stripe Reader

CHARGING INSTRUCTIONS


⦿ = LED Indicator Location Slow Flash = Normal Charge Solid Amber = Full Charge Fast Flash = Charging Error



Four Slot Spare Battery Charger




Single Slot Serial/USB Cradle




Four Slot Cradles

OPTIMUM IMAGING AND SCANNING POSITIONS


Laser Scanning




Standard Range Imaging



Long Range Imaging




OPTIMUM UPRIGHT BODY POSTURE



ALTERNATE LEFT AND RIGHT HANDS
TAKING BREAKS AND TASK ROTATION RECOMMENDED



AVOID EXTREME
WRIST ANGLES



AVOID EXTREME WRIST ANGLES


OPTIMUM BODY POSTURE

Low Scanning

Alternate left and right knees



AVOID BENDING



Alternate left and right hands



AVOID REACHING



High Scanning

Use a ladder



Taking breaks and
task rotation recommended



Zebra Technologies Corporation, Lincolnshire, IL U.S.A.
Zebra and the Zebra head graphic are registered trademarks of ZIH Corp. The Symbol logo is a registered
trademark of Symbol Technologies, Inc., a Zebra Technologies company.
© 2015 Symbol Technologies, Inc.



72-152191-02 Rev. A – February 2015



<http://www.zebra.com/mc919z>

MC919Z

Recommended Usage Guide