

---

# Release Notes TekSpeech Pro Agent 4.4.6

## Contents

---

[Description](#)

[Device Compatibility](#)

[Component Contents](#)

[Installation Requirements](#)

[Installation Instructions](#)

[Downloadable Software included in this Release](#)

## Description

---

The TekSpeech Pro Agent provides synchronization with the TekSpeech Pro Device and Operator Manager (DOM) to manage deployments to the device.

Updates since last release:

- (SPR-30879) Fixed dead end in device registration using loader file.
- Fixed PDK installation that failed but reported success.
- (SPR-29892) Fixed issue with voice logs reporting log file date time in UTC.
- Fixed issue with device status wipe.

## Device Compatibility

---

This software release supports the following devices.

Device	OS Version
WT4090	CE5
WT4090VOW	CE5
MC2180	CE6
MC9190	CE6
MC32N0	CE7
MC92N0	CE7
WT41N0	CE7
WT41N0VOW	CE7
MC92N0	WM
MC3190	WM
MC9190	WM

## Component Contents

---

Component	Version
Product Build Number	4.4.6 (4.04P06)

# Installation Requirements

---

Valid WIFI network connection with access to TekSpeech Pro Device and Operator Manager (DOM).

## Installation Instructions

---

### Manual installation instructions

1. Copy the matching (device and OS version) installation CAB file to your device into the \Application directory.
2. From the device, launch the installation CAB and choose the default options to install.
3. Export the “loader.ini” from the Devices/Device Group page in the TekSpeech Pro DOM.
4. Copy the “loader.ini” file into the \Application\MCL\ directory on the device and restart (warm reset) the device.

### Update installation instructions

1. From the TekSpeech Pro DOM, create a new configuration and choose the “TekSpeech Pro Agent” version “4.04P06” on the “Select product for your configuration” page of the configuration.

## Downloadable Software Included in this Release

---

Filename	Description
TEK_ADM_CE5_WT4090VOW_0404P06.cab	<b>Installation for WT4090VOW / CE5</b>
TEK_ADM_CE5_WT4090_0404P06.cab	<b>Installation for WT4090 / CE5</b>
TEK_ADM_CE6_MC2180_0404P06.cab	<b>Installation for MC2180 / CE6</b>
TEK_ADM_CE6_MC9190_0404P06.cab	<b>Installation for MC9190 / CE6</b>
TEK_ADM_CE7_MC32N0_0404P06.cab	<b>Installation for MC32N0 / CE7</b>
TEK_ADM_CE7_MC92N0_0404P06.cab	<b>Installation for MC92N0/ CE7</b>
TEK_ADM_CE7_WT41N0VOW_0404P06.cab	<b>Installation for WT41N0VOW / CE7</b>
TEK_ADM_CE7_WT41N0_0404P06.cab	<b>Installation for WT41N0 / CE7</b>
TEK_ADM_WM_MC3190_0404P06.cab	<b>Installation for MC3190 / WM</b>
TEK_ADM_WM_MC9190_0404P06.cab	<b>Installation for WT9190 / WM</b>
TEK_ADM_WM_MC92N0_0404P06.cab	<b>Installation for WT92N0 / WM</b>

Last Revised: <07-04-2017>