Release Notes - MC32N0 CE 7.0 - Premium BSP v00.51.17 - HotFix CFE v02.06.00 Package

Introduction

Description

Package Details

Device Compatibility

Installation Requirements
Installation Instructions

Release Date

Introduction

HotFix CFE (Cumulative Fixes from Engineering) Package contains multiple SPR Hotfixes into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision.

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies HotFix Package Policy. Click here to view HotFix Package Policy. HotFix Support Policy

Description

 $CFE\ package\ CFE_MC32_CE_05117_EN_v020600_WB.cab/CFE_MC32_CE_05117_EN_v020600_NB.cab\ file\ includes\ the\ following\ HotFixes: the package\ CFE_MC32_CE_05117_EN_v020600_NB.cab\ file\ f$

SPR No	Synopsis
28952	Sometimes the audio is not routed BT Headset or audio is not recorded through microphone when HS3000 BT Headset connected/disconnected several times manually with MC32CE device.
28478	Device intermittently takes up to 30 seconds or more to establish Ethernet network connection in Ethernet quad dock.
27963	During critical suspend (Batt Swap) audio was not getting routed to Headset on resume.
27364	Decoding delays for GS1 Barcodes when "Picklist Mode" is enabled.
26489	Plays audio through speakers instead of wired headset.
26471	URL bar is accessible when pressing TAB in IE Kiosk Mode.

 $This \ HotFix\ CFE\ package\ CFE_MC32_CE_05117_EN_v020600_WB. cab/CFE_MC32_CE_05117_EN_v020600_NB. cab \ obsoletes\ the\ following\ HotFix\ CFEs. \ obso$

HotFix CFE version	
CFE_MC32_CE_005117_EN_v010100_e.cab	
CFE_MC32_CE_005117_EN_v010200_e_NB.cab CFE_MC32_CE_005117_EN_v010200_e_WB.cab	
CFE_MC32_CE_05117_EN_v010400_e_WB.cab CFE_MC32_CE_05117_EN_v010400_e_NB.cab	
CFE_MC32_CE_05117_EN_v00500_e_WB.cab CFE_MC32_CE_05117_EN_v010500_e_NB.cab	

 $Note: Latest\ CFE\ package\ includes\ previous\ CFE\ package\ hot\ fixes\ and\ new\ SPR\ hot\ fix.$

Package Details

CFE_MC32_CE_05117_EN_v020600_WB.cab (CFE package with auto Warm boot)

CFE_MC32_CE_05117_EN_v020600_NB.cab (CFE package without auto Warm boot)

Device Compatibility

This HotFix CFE Package software release has been approved for use with the following Zebra devices

Device	Operating System	BSP Version
MC32N0	CE 7.0	v00.51.17

Installation Requirements

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM set up

Installation Instructions

For Normal installation of the PATCH:

- Windows Mobile Device Center (For Windows Desktops) Installation Instructions
 - 1. Copy "CFE_MC32_CE_05117_EN_v020600_WB.cab" file to the Application folder on the device.
 - 2. Deploy the solution by tapping on the "CFE_MC32_CE_05117_EN_v020600_WB.cab" file.
 - $3. \ \ After successful deployment of the "CFE_MC32_CE_05117_EN_v020600_WB. cab" file, device will do an automatic warm boot and the successful deployment of the "CFE_MC32_CE_05117_EN_v020600_WB. cab" file, device will do an automatic warm boot and the successful deployment of the "CFE_MC32_CE_05117_EN_v020600_WB. cab" file, device will do an automatic warm boot and the successful deployment of the "CFE_MC32_CE_05117_EN_v020600_WB. cab" file, device will do an automatic warm boot and the successful deployment of the "CFE_MC32_CE_05117_EN_v020600_WB. cab" file, device will do an automatic warm boot and the successful deployment of the "CFE_MC32_CE_05117_EN_v020600_WB. cab" file, device will do an automatic warm boot and the successful deployment of the succes$
- SD Cards / Micro SD cards Installation Instructions:
 - 1. Copy "CFE_MC32_CE_05117_EN_v020600_WB.cab" file to the SD card.
 - 2. Deploy the solution by tapping on the "CFE_MC32_CE_05117_EN_v020600_WB.cab"
 - $3. \ \ After successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm between the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm between the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm between the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm between the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm between the \ "CFE_MC32_CE_05117_EN_v020600_WB.cab" \ file, device will do an automatic warm between the \ "CFE_MC32_CE_05117_EN_v0206000_WB.cab" \ file, device will do an automatic warm between the \ "CFE_MC32_CE_05117_EN_v02060$

For MSP or REMOTE installation of the PATCH:

- $1. \quad Set up \ MDM \ (MSP, Soti, Airwatch, etc..) \ to send \ "CFE_MC32_CE_05117_EN_v020600_NB. cab" \ file \ to \ the \ application \ folder \ of \ the \ devices the \$
- $2. \ \ \, \text{To deploy the solution, setup in MDM to install the cab file "CFE_MC32_CE_05117_EN_v020600_NB.cab" files the cab file of the ca$
- $3. \ \ Changes will take effect after a manual reboot of the terminal or if MDM reboots device.$

Release Date

May, 2016