# Release notes for MC919Z RFID Software Release v2.2.5009 and Update Loader image 2.41.003

Release Notes for Version 2.2.5009

Released May 2013

#### **Contents**

Introduction	1
Software Download	1
Installation	1
Versions	2
Known issues	3
Questions	3
Disclaimer	3

#### Introduction

This *Release Notes is* for the MC919Z RFID handhelds RFID release v2.2.5009 and Windows Embedded Handheld (WEHH) 6.5 Update loader image release v2.41.003. This change has been made to accommodate the transition to a new display in the MC919Z RFID handheld devices. .

It contains two components

- 1. Updated OS BSP version 2.41.003: To support new display on the handheld devices
- 2. Updated RFID CAB file 2.2.5009 : To support new display on the handheld devices

#### **Software Download**

Software download is available at: http://support.symbol.com/

Version	File	Date	Size
2.41.03	9190w65HenUL024103.zip	Oct 2012	64.47MB
2.2.5009	MCRFIDInstall_2.2.5009.CAB	Oct 2012	4.29MB

### **Important Notes:**

This software is applicable for MC919Z RFID WEHH 6.5 devices. It will update the following two components

- Device OS: Windows Embedded HandHeld (WEHH) 6.5 (OEM version 2.41.03)
- RFID software: 2.2.5009

### Other salient points:-

- This image upgrade is being released to accommodate the display change on MC919Z devices.
- This new build will continue to support current existing hardware.

# Release notes MC9190-Z RFID Software Release v2.2.5009 and Update Loader image 2.41.003

# RFID features:-

The RFID features in 2.2.5009 are the same as 2.2.5008.

#### Other:-

- This OS and RFID cab file supports all the variants of the MC919Z RFID handheld devices.

#### Installation

# To install Update Loader image

IMPORTANT NOTE: All existing applications may be erased when this UpdateLoader is used. Please backup your date prior to commencing upgrade

- Copy all files in the "9190w65HenUL024103.zip" into the \Temp folder of device or into the root folder (\) of a SD card. Place SD card into device.
- Place device in cradle with external power during upgrade.
- Navigate to the \Temp folder Or to the root folder of the SD card
- Launch StartUpdLdr.exe. Device will proceed to install new OS.

#### To install mobile RFID software:

- Copy MCRFIDInstall 2.2.5009.CAB to \Temp folder on the terminal.
- Tap once on MCRFIDInstall\_2.2.5009.CAB to perform the installation.
- Confirm any prompt to uninstall/overwrite any existing version.
- Device will reboot after the installation and enable RFID service on the device.

#### **Versions**

Important version numbers of the new build are as follows.

OEM version	02.41.0003
OS version	29040.5.3.12
PowerMicro version	55.61.9007
Monitor Lite version	1.25.9010
IPL version	1.04.0000
CPLD version	2.0
Partition version	2.00.0000
OBM version	1.11.01
RFID version	2.2.5009

# Release notes for MC919Z RFID Software Release v2.2.5009 and Update Loader image 2.41.003

# **Known issues**

# Questions

For sales related enquiries, contact Motorola Inc. at 301 610-6100 (Monday-Friday 8:30 a.m. – 5:00 p.m. EST): http://www.symbol.com/rfid

For technical assistance please call Motorola at 800-653-5350 (24x7 support line): http://www.symbol.com/services/howto/howto\_contact\_us.html

# **Disclaimer**

While Motorola Inc. has committed its best efforts to providing accurate information in this document, we assume no responsibility for any inaccuracies that may be contained herein, and we reserve the right to make changes to this document without notice.

Motorola, Inc. One Motorola Plaza Holtsville, New York 11742-1300 http://www.symbol.com