Motion Computing Software Poloace Note	
	Motion Computing Software Release Note
Name	LE1600 BIOS A12
	LE1600-BIOSA12.zip
1	April 10, 2007
This Version	
1	A09 and all previous versions
•	LE1600 Tablet PCs
Supported Operating System	 Windows XP Tablet Edition 2005*, Version 2002, Service Pack 2 Installed Windows Vista, all versions except Windows Vista Home Basic Tablet Edition 2005 is included with the free Service Pack 2 download. If you have installed Windows XP Service Pack 2 on a tablet PC you now have Tablet Edition 2005
Overview BIOS A12 adjusts the	available graphics memory to meet Vista requirements set by Microsoft.
What's New In This Release	
Features Added: Changed the available graphics memory in XP and Vista based on system configuration (Vista requirement). Larger RAM configurations result in a greater amount of graphics memory available to the system.	
Known Issues and Limitations	
BIOS A12 is not compatible with the LE1600TC (Thin Client). Thin Client Tablets use a Solid State Drive with a size of 512MB and 1GB in lieu of a normal Hard Drive (30GB/60GB in size). If you are unsure if your unit is a LE1600TC please contact support before attempting to install this BIOS.	
Installation and Configuration Instructions	
To install the A12 BIOS update, do the following:	

Download the BIOS A12 file (LE1600A12A.zip) to the directory location of your choice. Unzip the file to a location on your local drive. From within the unzipped directory run the .exe file to install the BIOS upgrade.

Licensing

Refer to your applicable end-user licensing agreement for usage terms