

**123Scan Software Suite**

**Demo App**

**One Scanner meets all your apps needs**

## Table of Contents

<b>Product Overview .....</b>	<b>3</b>
Demo App Functionality.....	3
<b>Demo Hardware and Props.....</b>	<b>4</b>
Scanning Props.....	4
<b>Application Walkthrough.....</b>	<b>5</b>
Start Screen .....	5
Scan Data .....	5
Enterprise Console .....	6
Device Update.....	7
<b>Real Time Alerts - Virtual Tether .....</b>	<b>8</b>
<b>Appendix.....</b>	<b>9</b>
Items to be scanned for <i>Scan Data</i> .....	9

# Product Overview

## **Zebra Software Scanner Suite – One scanner meets ALL your App needs:**

This app enables a sales associate to demonstrate many of the newest scanning capabilities from Zebra. Many of these software capabilities are not only industry-first but also exclusive to Zebra. These features are available for free with the purchase of a Zebra scanner.

### Demo App Functionality:

1. **Scanning into Active PC Window** – Using Zebra’s industry first/only “DataWedge for Scanners”, a Zebra scanner can scan into whatever application has your PC’s focus.
2. **Virtual Tether RTA (Real Time Alerts) paging to Manager** – When scanner goes out of range (simulate by unplugging cable through USB switch), page EMC ET40 tablet (vibrate, beep and pop-up message – “Scanner from Room 214 Moved Out of Area”).
3. **Enterprise Console** – Have access to your entire fleets worth of scanner asset information using Zebra’s industry first/only “IoT Connector” (IoTC).
4. **Device Update** – Stimulated Fleet wide firmware and configuration update support.

## Demo Hardware and Props:

The following supplies must be assembled to set up the demo:

1. Demo App (Zebra Scanner Capability App)
2. Windows PC
3. USB Switch 
4. WiFi Router
5. DS8178 + Cradle
6. DS8178 HC + Cradle

Real Time Alerts - Virtual Tether (Optional):


7. EMC ET40 Tablet for Health care
8. TC22 for Retail

### **Scanning Props:**

- a. Patient ID barcode
- b. Blood bag barcode
- c. Medicine barcode



# Application Walkthrough:

## Start Screen:



## Scan Data:

When you scan a barcode, such as a data link, the data will appear in the host and barcode details will be displayed in the "**Scan Data**" tab. Depending on the barcode scanned, it will be assigned to the appropriate window. So, when a blood bag barcode is scanned, the "**Blood Bag Scanning**" window appears with the barcode information. Real barcodes can be found in the appendix below.



## Enterprise Console:

Once the “Enterprise Console” button is clicked, the user can see the following information:



- Number of Zebra devices
- Scanners
- Scanner models
- Cradles
- Cradle models



- Scanner firmware
- Cradle firmware
- Scanner configuration
- Cradle configuration

The screenshot shows the Enterprise Console dashboard with the following data:

**Zebra Alerts**

Time: All time | Division: All | Facility: All | Help Files

Battery Charge Alerts				
Division #	Facility #	Model #	Serial Number #	Charge % #
Gulf Coast		DS8178-HC4F8001MW	ZD01587615	18


Battery Charge Cycle Alerts				
Division #	Facility #	Model #	Serial Number #	Charge Cycles #
Gulf Coast		DS8178-HC4F8001MW	ZD01587615	475

Default Configuration Alerts				
Division #	Facility #	Model #	Serial Number #	Configuration #
Capital		DS8188-HC4800B7ZW	ZD01163120	Factory Defaults
Capital		DS8188-HC4800B7ZW	ZD039412271	Factory Defaults
North Florida		CR8178-SC180F4MW	Z5C246955	Factory Defaults
North Florida		CR8178-SC180F4MW	Z5C2429846	Factory Defaults
North Florida		CR8178-SC180F4MW	Z5C26134975	Factory Defaults
North Florida		CR8178-SC180F4MW	Z5C26924984	Factory Defaults

- Battery charge alerts
- Battery charge cycle alerts
- Default configuration alerts

## Device Update:

Click on “**Device Update**”, then follow the given prompts which lead to firmware update.




Followed by “Supported Operating Systems”



## Real Time Alerts - Virtual Tether:

When the scanner goes out of range from the computer/cradle, the Virtual Tether alarm goes off or can manually be activated by using the USB switch shown in the picture below to locate the scanner.




USB Switch to activate RTA:



Once the alarm is activated and the scanner has been detected, the following image will be seen on the tablet. To activate the alarm on the tablet, both the computer/laptop and the tablet need to be connected to the same network.

Screen seen on tablet: Tablet vibrates, beeps and pops up this message.




**Scanner from Room 214  
Moved Out of Area**



# Appendix

## Items to be scanned for *Scan Data*

Patient data:

87664321  **SMITH, BARBARA** **DOB 1/1/46**  87664321  
**MRN: 87654321** **Blood A+**  
   

Blood bag data:

  
**W1234 19 123456**   **R**  
Digi-Trax Corp  
Lincolnshire, IL 60069  
FDA Registration Number 1044593

  
0600 **A**

**Rh NEGATIVE**

Properly identify intended recipient.  
See circular of information for indications,  
contraindications, cautions, and methods of infusion.  
This product may transmit infectious agents.  
Rx only

**VOLUNTEER DONOR**

  
E1234V00

**THAWED APHERESIS  
FRESH FROZEN PLASMA**  
\_\_\_\_\_ mL containing approx \_\_\_\_\_ mL  
ACD - B  
Store at 1 to 6 C  
Prepared by a manual procedure

  
0192821025 Expiration  
Date/Time  
**09 OCT 2019 10:25**

  
N0008

Medicine data:

