



## Cleaning and Disinfecting Zebra MC40-HC Mobile Computers

The Zebra MC40-HC mobile computer is hard at work in healthcare facilities around the world. The fully-featured pocket sized device helps improve patient safety, the patient experience and staff productivity.

Just as with other devices that come into contact with patients, surfaces and healthcare workers, the MC40-HC should be cleaned after use with every patient and disinfected at regular intervals to reduce the risks associated with the spread of healthcare associated infections (HAIs) and microorganisms. The MC40-HC was specifically designed and built for the rigors of healthcare environments and can withstand repeated cleaning and disinfecting practices. It is important to use approved cleaning and disinfectant products to ensure that HAIs and microorganisms are removed and that the device is protected.

## Approved Disinfectant Products for Zebra MC40-HC

Clorox - Dispatch with Bleach

Clorox Healthcare Bleach Germicidal Wipes

Diversey- Dimension 256 Neutral Disinfectant Cleaner

Diversey - Virex II 256

Metrex - CaviWipes

Steris - Coverage Plus Germicidal Surface Wipes

PDI Sani Cloth Plus

PDI Super Sani Cloth Germicidal Wipes

Sani Professional Sani-Wipes

SC Johnson - Windex Original Glass Cleaner

The Clorox Company - 409 Glass and Surface Cleaner

PDI Sani-Hands

## Non-Approved Disinfectant Products for Zebra MC40-HC

The use of Non-Approved agents has potential to damage the product and should be avoided.

## Non-Approved Disinfectant Products for Zebra MC40-HC

Diversey - Oxiver Wipes

Metrex - CaviWipes1

PDI - Sani-Cloth HB

PDI - Sani-Cloth AF3

For hospitals to protect patients and staff, it is critical to put a robust infrastructure of infection protection practices in place that includes the cleaning and disinfection of all mobile devices used by healthcare workers.

For more information about the MC40-HC, visit

www.zebra.com/MC40HC

