



Motion Computing Software Release Note

Name	Intermec DLL 2.1.0.8
File Name	C5_F5_Intermec_v2108.zip
Release Date	October 13, 2009
This Version	2.1.0.8
Replaces Version	2.0.1.5 and all previous versions
Intended Users	Motion Computing advises all C5 and F5 users to install this update.
Intended Product	C5 and F5 Tablet PCs ONLY
File Size	96 Kb
Supported Operating System	<ul style="list-style-type: none">Windows XP Tablet Edition 2005*, Version 2002, Service Pack 2 - Installed.Windows Vista, all versions except Windows Vista Home Basic. <p>* Tablet Edition 2005 is included with the free Service Pack 2 download. If you installed Windows XP Service Pack 2 on a Tablet PC, you now have Tablet Edition 2005.</p>

Fixes in this Release

- Resolves a memory leak that can cause the barcode reader to stop responding after repeated use under certain conditions.

Known Issues and Limitations

None

Installation and Configuration Instructions

To install this version update, perform the following steps:

NOTE: Do not activate the bar code reader until after the new DLL is installed in the correct directory.

- Restart the tablet.
- Download this update (C5_F5_Intermec_v2108.zip) to the directory location of your choice.
- Unzip the file to a location on your local drive.
- Copy or move the new DLL file into the C:\Windows\system32 folder.

Licensing

Refer to your applicable end-user licensing agreement for usage terms.