



Motion Computing Software Release Note

Name	OmniPass Fingerprint Reader
File Name	LE1600-OmniPassv35101.zip
Release Date	September 19, 2005
This Version	03.51.01
Replaces Version	03.01.36 and older
Intended Product	Motion Computing LE1600 Tablet PC <u>Only</u>
Supported Operating System	<ul style="list-style-type: none">• Windows XP Tablet PC Edition, Version 2002, Service Pack1• Windows XP Tablet Edition 2005*, Version 2002, Service Pack 2• Windows XP Embedded <p>* Tablet Edition 2005 is included with the free Service Pack 2 download. If you have installed Windows XP Service Pack 2 on a tablet PC you now have Tablet Edition 2005</p>

Overview

Omni Pass software and drivers enable the use of the fingerprint reader that is integrated with the LE1600 Tablet PC.

What's New In This Release

Enhancements

- Password Wizard – Provides users the ability to authenticate other third party applications
- Password Vault – Added ability to edit fields in the vault
- Added selection for designation of the desired Encryption Algorithms
- Improved Interface and Usability
- Finger Print Reader (FPR) now Scroll Window Capable for some windows

Critical Fixes

- User trying to encrypt folder with more then 2GB data. User can lose data because of improper error code handling that occurred due to MS Access 2GB database file limit.
- For Non-admin user trying to encrypt a folder on the root drive on a NTFS file system the source folder could be deleted and the user could lose data. This issue was introduced in version 3.50.22.

Notable Non-Critical Fixes

- Encrypting/Decrypting file with name more than 256 characters
- Dragging an encrypted file to an encrypted folder. The contents of the source folder were incorrect

- Password replacement where credentials were not being filled in the right window
- Enterprise edition - the super user password was getting corrupted because of a race condition
- "Change Password" Option becomes visible when user logs off from OmniPass

Known Issues and Limitations

There are no known issues or limitations at this time.

Installation and Configuration Instructions

To install the OmniPass 3.51.01 Update, do the following:

1. Download the OmniPass 3.51.01 zip file (3.51.01.zip) to the directory location of your choice
2. Unzip the file and extract all files
3. Navigate into the newly created directory
4. Run Setup.exe, following displayed instructions

Licensing

Refer to your applicable end-user licensing agreement for usage terms