



## Motion Computing Software Release Note

Name	<b>OmniPass 8.01.19</b>
File Name	<b>Omnipass_64-bit_8.01.19.zip</b>
Release Date	October 9, 2014
This Version	8.01.19
Replaces Version	All previous versions
Intended Users	<b>Motion R12 users</b>
Intended Product	Motion R12 Tablet PCs ONLY
File Size	50 MB
Supported Operating System	Windows 7 64-bit

### Fixes in this Release

- Translation errors in French and German languages
- Black screen after hit "Ctrl\_Alt\_Del" during log on to a domain account

### What's New In This Release

N/A

### Known Issues and Limitations

- Windows 8 Modern Internet Explorer password entering is not supported.

### Installation and Configuration Instructions

To install this version update, perform the following steps:

1. Download this update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Back up your existing OmniPass profile (see OmniPass Help for details).
4. Double-click the installer (setup.exe) and follow the prompts.

Silent mode installation instructions:

Command line statement to install in silent mode – "Setup.exe /s"

Command line statement for silent uninstall –

64 bit: "\\Program Files (x86)\InstallShield Installation Information\{314FAD12-F785-4471-BCE8-AB506642B9A1}\Setup.exe" /s.

### Licensing

Refer to your applicable end-user licensing agreement for usage terms.