



Motion Computing Software Release Note

Name	C5 & F5 BIOS A13
File Name	C5_F5_BIOS_A13.zip
Release Date	December 15, 2008
This Version	A13
Replaces Version	A12 and all previous versions
Intended Users	Motion Computing advises all C5 and F5 users to install this update. See <i>Fixes in this Release</i> and <i>Known Issues and Limitations</i> below for more details.
Intended Product	C5 and F5 Tablet PCs only
Supported Operating System	<ul style="list-style-type: none">Windows XP Tablet Edition 2005*, Version 2002, Service Pack 2 - Installed.Windows Vista, all versions except Windows Vista Home Basic. <p>* Tablet Edition 2005 is included with the free Service Pack 2 download. If you installed Windows XP Service Pack 2 on a Tablet PC, you now have Tablet Edition 2005.</p>

Fixes in this Release

- Added a feature to prevent system power-on when running the tablet on battery power and when the battery charge is less than 3%
- Prevents the bar code reader LED from flashing during POST
- Fixed a battery drain issue when the tablet is in standby or hibernate
- Fixed a battery charge issue when docking and undocking the tablet

Installation and Configuration Instructions

To install the A13 BIOS update:

1. Download the BIOS A13 file (C5_F5_BIOS_A13.zip) and save it to a directory of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click *Motion BIOS A13.exe* and follow the prompts.
Note: Ensure the tablet is using AC power before opening the file.
4. The update process may take some time. Do not manually power-off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

Licensing

Refer to your applicable end-user licensing agreement for usage terms.