



Motion Computing Software Release Note

Name	C5m & F5m BIOS A01
File Name	X5m_A01_BIOS.zip
Release Date	April 9, 2015
This Version	A01
Replaces Version	All previous versions
Intended Users	Motion Computing C5m and F5m users
Intended Product	Motion Computing C5m and F5m Tablet PCs only
File Size	9 MB
Supported Operating System	Windows 8.1 (64-bit) and Windows 7 (64-bit)

Fixes in this Release

- Update Computrace Option ROM to version 945.
- Enable S4/S5 AC plug-in auto wake function.
- Modify Battery Read function to fix incorrect Critical Battery Event.
- Remove unpopulated COM4 in device manager.

Installation and Configuration Instructions

Note: Ensure the tablet is using AC power before installing the BIOS update.

To install the C5m & F5m BIOS A01 update, perform the following steps:

1. Download the BIOS update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click installer (.exe file) and follow the prompts.
4. System will restart automatically to complete the BIOS update process. Do not manually power off the tablet during the update.
5. The tablet will automatically restart after installing the BIOS.

Licensing

Refer to your applicable end user licensing agreement for usage terms.