



## Xplore Technologies Software Release Note

Name	<b>C5m &amp; F5m BIOS A02</b>
File Name	<b>X5m_A02_BIOS.zip</b>
Release Date	May 28, 2015
This Version	A02
Replaces Version	All previous versions
Intended Users	<b>Motion Computing C5m and F5m users</b>
Intended Product	Motion Computing C5m and F5m Tablet PCs only
File Size	15 MB
Supported Operating System	Windows 8.1 (64-bit) and Windows 7 (64-bit)

### Fixes in this Release

- Change the ACPI ID of Motion Button Device to MCO0107
- Including Thermal Policy for Innolux Panel

### What's New in this Release

N/A

### Installation and Configuration Instructions

**Note:** Ensure the tablet is using AC power before installing the BIOS update.

**To install the C5m & F5m BIOS A02 update, perform the following steps:**

1. Download the BIOS update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click installer (.exe file) and follow the prompts.
4. System will restart automatically to complete the BIOS update process. Do not manually power off the tablet during the update.
5. The tablet will automatically restart after installing the BIOS.

### Licensing

Refer to your applicable end user licensing agreement for usage terms.