



Motion Computing Software Release Note

| | |
|----------------------------|---|
| Name | C5t & F5t BIOS A04 |
| File Name | CF5t_A04_BIOS.zip |
| Release Date | January 15, 2013 |
| This Version | A04 |
| Replaces Version | All previous versions |
| Intended Users | Motion Computing C5t and F5t users |
| Intended Product | Motion Computing C5t and F5t Tablet PCs only |
| File Size | 2 MB |
| Supported Operating System | Windows 8 (32-bit/64-bit) Windows 7 (32-bit/64-bit) Windows XP (32-bit) |

Fixes in this Release

- Fix system hang at setup menu when 'CMOS Reset' is enabled.
- Improve failure rate when press power button immediately after unplugging AC adapter which would cause system to hang on resume from sleep.

What's New in this Release

- Add USB side port Windows debugger support (BIOS setup selection).
- Add brightness bar support for XP Tablet.
- Add LAN support for XP Tablet.
- Add USB side port support for XP Tablet.

Known Issues and Limitations

- N/A

Installation and Configuration Instructions

Note: Ensure the tablet is using AC power before installing the BIOS update.

To install the BIOS update:

1. Download the BIOS update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click installer and follow the prompts.
4. The update process may take some time. Do not manually power off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

Licensing

Refer to your applicable end-user licensing agreement for usage terms.