



Motion Computing Software Release Note

Name	C5t & F5t BIOS A08
File Name	CF5t_A08_BIOS.zip
Release Date	July 21, 2014
This Version	A08
Replaces Version	All previous versions
Intended Users	Motion Computing C5t and F5t users
Intended Product	Motion Computing C5t and F5t Tablet PCs only
File Size	2 MB
Supported Operating System	Windows 7 (32-bit/64-bit)

Fixes in this Release

- Fix U-Blox GPS Location Sensor not appearing in Device Manager for Win7

What's New in this Release

N/A

Installation and Configuration Instructions

Note: Ensure the tablet is using AC power before installing the BIOS update.

To install the C5t & F5t BIOS A08 update, perform the following steps:

1. Download the BIOS update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click installer (.exe file) and follow the prompts.
4. The update process may take some time. Do not manually power off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

Licensing

Refer to your applicable end user licensing agreement for usage terms.