



Motion Computing Software Release Note

Name	C5te & F5te BIOS A06
File Name	X5te_A06_BIOS.zip
Release Date	October 09, 2014
This Version	A06
Replaces Version	All previous versions
Intended Users	Motion Computing C5te and F5te users
Intended Product	Motion Computing C5te and F5te Tablet PCs only
File Size	2.2 MB
Supported Operating System	Windows 8 (64-bit) and Windows 7 (32-bit/64-bit)

Fixes in this Release

- Boot priority order is not preserved after removing USB key
- Winmagic SecureDoc Pre-boot Authentication doesn't work on Windows 7

What's New in this Release

N/A

Installation and Configuration Instructions

Note: Ensure the tablet is using AC power before installing the BIOS update.

To install the C5te & F5te BIOS A06 update, perform the following steps:

1. Download the BIOS update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click installer (.exe file) and follow the prompts.
4. The update process may take some time. Do not manually power off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

Licensing

Refer to your applicable end user licensing agreement for usage terms.