



Motion Computing Software Release Note

Name	CL910 BIOS A05
File Name	CL910_A05_BIOS.zip
Release Date	July 9, 2013
This Version	A05
Replaces Version	All previous versions
Intended Users	Motion Computing CL910 users
Intended Product	Motion Computing CL910 Tablet PCs only
File Size	2.2 MB
Supported Operating System	Windows 7 (32-bit), all versions

Fixes in this Release

- WWAN card couldn't be detected under a rare condition.
- Adjusted LCD screen brightness level.

Installation and Configuration Instructions

Note: Ensure the tablet is using AC power before installing the BIOS update.

To install the CL910 BIOS A05 update, perform the following steps

1. Download the BIOS update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click the installer (.exe file) and follow the prompts.
4. The update process may take some time. Do not manually power off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

Licensing

Refer to your applicable end user licensing agreement for usage terms.