



Motion Computing Software Release Note

Name	CL910 BIOS A07
File Name	CL910_A07_BIOS.zip
Release Date	October 7, 2014
This Version	A07
Replaces Version	All previous versions
Intended Users	Motion Computing CL910 users
Intended Product	Motion Computing CL910 Tablet PCs only
File Size	2.2 MB
Supported Operating System	Windows 7 (32-bit), all versions

What's New in this Release

- Add battery ship mode support

Installation and Configuration Instructions

Note: Ensure the tablet is using AC power before installing the BIOS update.

To install the CL910 BIOS A07 update, perform the following steps

1. Download the BIOS update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click the installer (.exe file) and follow the prompts.
4. The update process may take some time. Do not manually power off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

Licensing

Refer to your applicable end user licensing agreement for usage terms.