



## Motion Computing Software Release Note

Name	<b>CL920 BIOS A03</b>
File Name	<b>CL920/CL920_A03_BIOS.zip</b>
Release Date	January 20, 2015
This Version	A03
Replaces Version	All previous versions
Intended Users	<b>Motion Computing CL920 users</b>
Intended Product	Motion Computing CL920 Tablet PCs only
File Size	13 MB
Supported Operating System	Windows 8 (64-bit) and Windows 7 (32-bit/64-bit)

### Fixes in this Release

- Add F12 key support in DOS and PXE boot

### What's New in this Release

- Use native panel EDID clock to improve touch functions

### Installation and Configuration Instructions

**Note:** Ensure the tablet is using AC power before installing the BIOS update.

**To install the CL920 BIOS A03 update, perform the following steps**

1. Download the BIOS update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click the installer (.exe file) and follow the prompts.
4. The update process may take some time. Do not manually power off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

### Licensing

Refer to your applicable end user licensing agreement for usage terms.