



## Motion Computing Software Release Note

Name	<b>CL900 BIOS A03</b>
File Name	<b>CL900_BIOS_A03.zip</b>
Release Date	July 18, 2011
This Version	A03
Replaces Version	All previous versions
Intended Users	<b>Motion Computing CL900 users</b>
Intended Product	Motion Computing CL900 Tablet PCs only
File Size	3 MB
Supported Operating System	Windows 7 (32-bit), all versions.

### Fixes in this Release

- Fix occasional BIOS no bootable device under heavy system load.
- Update PXE ROM to enable PXE Boot.
- Resolve possible no POST scenario.
- Add battery ACPI information.
- Correct typo in BIOS help text.
- Resolve occasional boot hang at Motion logo.
- Update V-BIOS to latest version.
- Set LAN device to un-removable in Device and Printers.
- Remove HD password option in BIOS setup.

*Motion has removed the ability to set a hard drive password within the BIOS of our systems. Motion is no longer able to provide support for this feature and as a result we are no longer offering it.*

### Installation and Configuration Instructions

#### To install the BIOS update:

1. Download the BIOS file and save it to a directory of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click the installer and follow the prompts.  
Note: Ensure the tablet is using AC power before opening the file.
4. The update process may take some time. Do not manually power-off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

### Licensing

Refer to your applicable end-user licensing agreement for usage terms.