



## Motion Computing Software Release Note

Name	<b>CL900 BIOS A06</b>
File Name	<b>CL900_A06_BIOS.zip</b>
Release Date	November 29, 2011
This Version	A06
Replaces Version	All previous versions
Intended Users	<b>Motion Computing CL900 users</b>
Intended Product	Motion Computing CL900 Tablet PCs only
File Size	3 MB
Supported Operating System	Windows 7 (32-bit), all versions.

### Fixes in this Release

- Fix occasional no bootable device error during power on or restart.
- Add Windows DMI programming support.
- Fix SSD full disk encryption application latency issue.
- Fix BIOS crisis recovery EEPROM sync issue.
- Fix occasional display flicker issue.

### Installation and Configuration Instructions

#### To install the BIOS update:

1. Download the BIOS file and save it to a directory of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click the .exe installer and follow the prompts.  
Note: Ensure the tablet is using AC power before opening the file.
4. The update process may take some time. Do not manually power-off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

### Licensing

Refer to your applicable end-user licensing agreement for usage terms.