



Motion Computing Software Release Note

Name	CL900 BIOS A07
File Name	CL900_A07_BIOS.zip
Release Date	July 23, 2012
This Version	A07
Replaces Version	All previous versions
Intended Users	Motion Computing CL900 users
Intended Product	Motion Computing CL900 Tablet PCs only
File Size	3 MB
Supported Operating System	Windows 7 (32-bit), all versions.

Fixes in this Release

- Add additional manufacturing settings.

Installation and Configuration Instructions

To install the BIOS update:

1. Download the BIOS file and save it to a directory of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click the .exe installer and follow the prompts.
Note: Ensure the tablet is using AC power before opening the file.
4. The update process may take some time. Do not manually power-off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

Licensing

Refer to your applicable end-user licensing agreement for usage terms.