



Motion Computing Software Release Note

Name	LE1700 BIOS A10
File Name	LE1700_BIOS_A10.zip
Release Date	January 16, 2008
This Version	A10
Replaces Version	A09 and all previous versions
Intended Users	Motion Computing advises all LE1700 users to install this update. See Fixes in this Release and Known Issues and Limitations below for more details.
Intended Product	LE1700 Tablet PCs ONLY
File Size	576 KB
Supported Operating System	<ul style="list-style-type: none">Windows XP Tablet PC Edition 2005* Version 2002 Service Pack 2Windows Vista, all versions except Windows Vista Home Basic <p>* Tablet Edition 2005 is included with the free Service Pack 2 download. If you have installed Windows XP Service Pack 2 on a Tablet PC you have Tablet Edition 2005.</p>

Fixes in this Release

- TPM will now initialize correctly if you enable it in the BIOS and then install the TPM software.
- Critical Battery Alarm level changed from 3% to 2%.
- Improved PXE Boot function.

Known Issues and Limitations

- PXE boot (network-based boot) cannot be disabled in BIOS.
- Windows Vista ignores Critical Battery settings stored in BIOS. This is an issue with Windows Vista.

Installation and Configuration Instructions

To install the LE1700 A10 BIOS update:

1. Download the BIOS A10 file (LE1700_BIOS_A10.zip) and save it to a directory of your choice.
2. Unzip the file to a location on your local drive.
3. Start WinPhlash. In Windows Vista you can run WinPhlash as an Administrator by right-clicking the WinPhlash icon and selecting **Run as administrator**.
4. Select the LE1700_A10.wph BIOS file and click the **Flash BIOS** button.

Note: You will have to restart your computer after installing the BIOS.

Licensing

Refer to your applicable end-user licensing agreement for usage terms.