



## Cleaning and Disinfecting Zebra MC40-HC Mobile Computers

The Zebra MC40-HC mobile computer is hard at work in healthcare facilities around the world. The fully-featured pocket sized device helps improve patient safety, the patient experience and staff productivity.

Just as with other devices that come into contact with patients, surfaces and healthcare workers, the MC40-HC should be cleaned after use with every patient and disinfected at regular intervals to reduce the risks associated with the spread of healthcare associated infections (HAIs) and microorganisms. The MC40-HC was specifically designed and built for the rigors of healthcare environments and can withstand repeated cleaning and disinfecting practices. It is important to use approved cleaning and disinfectant products to ensure that HAIs and microorganisms are removed and that the device is protected.

**FACT SHEET**

CLEANING AND DISINFECTING ZEBRA MC40-HC MOBILE COMPUTERS

**Approved Disinfectant Products for Zebra MC40-HC**

|  |
|--|
| Clorox - Dispatch with Bleach                        |
| Clorox Healthcare Bleach Germicidal Wipes            |
| Diversey- Dimension 256 Neutral Disinfectant Cleaner |
| Diversey - Virex II 256                              |
| Metrex - CaviWipes                                   |
| Steris - Coverage Plus Germicidal Surface Wipes      |
| PDI Sani Cloth Plus                                  |
| PDI Super Sani Cloth Germicidal Wipes                |
| Sani Professional Sani-Wipes                         |
| SC Johnson - Windex Original Glass Cleaner           |
| The Clorox Company - 409 Glass and Surface Cleaner   |
| PDI Sani-Hands                                       |

**Non-Approved Disinfectant Products for Zebra MC40-HC**

The use of Non-Approved agents has potential to damage the product and should be avoided.

**Non-Approved Disinfectant Products for Zebra MC40-HC**

|                         |
|-------------------------|
| Diversey - Oxiver Wipes |
| Metrex - CaviWipes1     |
| PDI - Sani-Cloth HB     |
| PDI - Sani-Cloth AF3    |

**For hospitals to protect patients and staff, it is critical to put a robust infrastructure of infection protection practices in place that includes the cleaning and disinfection of all mobile devices used by healthcare workers.**

**For more information about the MC40-HC, visit**  
[www.zebra.com/MC40HC](http://www.zebra.com/MC40HC)



**NA and Corporate Headquarters**  
+1 800 423 0442  
inquiry4@zebra.com

**Asia-Pacific Headquarters**  
+65 6858 0722  
contact.apac@zebra.com

**EMEA Headquarters**  
zebra.com/locations  
mseurope@zebra.com

**Latin America Headquarters**  
+1 847 955 2283  
la.contactme@zebra.com