

# Release Notes - Zebra ET8XX Tablet Software

ET8X-WIN11PRO-081222\_Z01.3
Windows 11 Pro OS Recovery Package

## **Device Support**

The products supported in this release: ET80A, ET85B, ET85C.

Please see Device compatibility details under Addendum Section.

#### **Known Constraints**

- Wi-Fi roaming from non-DFS channel to DFS channel may take longer.
- · Stylus fine pen strokes may be partially lost, but this does not affect handwriting text recognition
- Vehicle dock with 7-port Port Expander Module (PEM) at high temperature may lose connection
- Keyboard LEDs cannot be turned off when device is in Quiet Mode

#### **Software Packages**

Package Name	Description
ET8X-WIN11PRO-081222_Z01.3-BIOS-A04_AUTOINSTALLER.zip	Full Windows 11 Pro OS recovery image combined with BIOS and EC firmware.

#### **Version Information**

Major Windows and product-specific component versions

Component / Description	Version
Zebra OS Build Revision	081222_Z01.3
Windows 11 Professional OS Build	10.0.22000
Windows 10 Pro Feature Experience Pack	21H2
BIOS	A04
Drivers	
Intel Chipset Driver (Tiger Lake)	10.1.24.6



Intel Dynamic Tuning Technology	8.7.10700.22502
Intel GNA Scoring Accelerator module	3.0.0.1363
Intel HID Event Filter	2.2.1.386
Intel Integrated Sensor Solution	3.1.0.4477
Intel Management Engine Interface	2210.2.80.0
Intel Serial IO (GPIO, I2C, SPI, UART)	30.100.2129.8
Intel Smart Sound Technology	10.29.0.6815
Intel Wireless Bluetooth	22.160.0.3
Intel Wi-Fi 6E AX210 160 MHz	22.150.1.1
Intel Ethernet Connection I219-M	12.19.1.37
Intel Irtis Xe Graphics	30.0.101.3111
Intel TGL AVStream Camera (IPU)	60.22000.6.6634
Intel Rear Camera Sensor AR1337	60.22000.6634.2
Intel Rear Camera Sensor AR1337  Intel NxpNfcClient Driver	60.22000.6634.2
Intel NxpNfcClient Driver  Quectel PCI Express (if EM121-4G WWAN present) Quectel PCI Express Quectel EM121R-GL Quectel Wireless Location Sensor Quectel QMUX Interconnect Quectel MBIHV Mobile Broadband Firmware Device	12.0.6.0 1.0.0.14 1.0.0.7 1.0.89.0 1.0.89.3 1.10.2.29
Intel NxpNfcClient Driver  Quectel PCI Express (if EM121-4G WWAN present) Quectel PCI Express Quectel EM121R-GL Quectel Wireless Location Sensor Quectel QMUX Interconnect Quectel MBIHV Mobile Broadband Firmware Device HighSpeed USB Composite Device(UDE)  Quectel PCI Express (if RM505-5G WWAN present) Quectel PCI Express Generic Mobile Broadband Adapter Quectel Wireless Location Sensor Quectel QMUX Interconnect Quectel UDE Device	12.0.6.0  1.0.0.14 1.0.0.7 1.0.89.0 1.0.89.3 1.10.2.29 30.0.0.0  1.0.0.13 (inbox) 1.0.0.4 1.0.0.6 1.0.0.11
Intel NxpNfcClient Driver  Quectel PCI Express (if EM121-4G WWAN present) Quectel PCI Express Quectel EM121R-GL Quectel Wireless Location Sensor Quectel QMUX Interconnect Quectel MBIHV Mobile Broadband Firmware Device HighSpeed USB Composite Device(UDE)  Quectel PCI Express (if RM505-5G WWAN present) Quectel PCI Express Generic Mobile Broadband Adapter Quectel Wireless Location Sensor Quectel QMUX Interconnect Quectel UDE Device HighSpeed USB Composite Device(UDE)	12.0.6.0  1.0.0.14 1.0.0.7 1.0.89.0 1.0.89.3 1.10.2.29 30.0.0.0  1.0.0.13 (inbox) 1.0.0.4 1.0.0.6 1.0.0.11 30.0.0.0
Intel NxpNfcClient Driver  Quectel PCI Express (if EM121-4G WWAN present) Quectel PCI Express Quectel EM121R-GL Quectel Wireless Location Sensor Quectel QMUX Interconnect Quectel MBIHV Mobile Broadband Firmware Device HighSpeed USB Composite Device(UDE)  Quectel PCI Express (if RM505-5G WWAN present) Quectel PCI Express Generic Mobile Broadband Adapter Quectel Wireless Location Sensor Quectel QMUX Interconnect Quectel UDE Device HighSpeed USB Composite Device(UDE)  Thunderbolt HSA Component	12.0.6.0  1.0.0.14 1.0.0.7 1.0.89.0 1.0.89.3 1.10.2.29 30.0.0.0  1.0.0.13 (inbox) 1.0.0.4 1.0.0.6 1.0.0.11 30.0.0.0  1.41.1335.0



Utilities/Applications	
(DOCK) DisplayLink Graphics Driver	10.2.6943.0
(DOCK) Realtek LAN Driver	10.5.920.2015
Realtek High Definition Audio Driver - ALC888	6.0.9244.1
Touch Mode	1.0.1
Keyboard Color App	1.1.7
Keyboard Programmable Button Setting	1.0.7
xKnowTab (Know Your Tablet)	3.6.5
Zebra Technologies E-Label	1.0.5
Zebra Scanner Driver (if scanner is present)	3.07.0004

### **Usage Notes**

To apply the image:

Creating Installation USB Stick

Follow these steps to create bootable installation USB stick.

This is critical: Only FAT32 format is recognized by the tablet BIOS for the steps below.

Note: Use 16GB stick or larger.

- 1. Insert USB stick to Windows PC.
- 2. From Windows Explorer right click USB stick and Format to FAT32.
- 3. Rename stick as "BOOTME" by right click in Explorer and rename.
- 4. Download OS image zip file, extract the contents into a folder and copy entire contents of this folder to the root of the formatted installation USB stick.

NOTE: Make sure image is downloaded completely. Check the size of the downloaded image versus image posted on the Support Central at Zebra.com. Partial downloads may corrupt the device.

- 5. Attach installation USB stick to tablet USB port/USB hub.
- 6. Attach AC power.



- 7. Power on the tablet, at BIOS splash screen, tap touch screen or F12 to access the BIOS boot menu.
- 8. At the BIOS boot menu select to boot to the inserted USB device.
- 9. Installation automation will load the recovery image files.
- 10. When imaging is complete, remove the USB stick and the device will shut down.
- 11. To complete the installation, power on the device, the system will reboot several times then shutdown.
- 12. Power on system to begin the Out of Box Experience phase of the Windows Installation.

#### **New Features**

Initial release

### **Resolved Issues**

Initial release

### **Important Links**

- · Zebra Techdocs
- Developer Portal

### **Addendum**

### **Device Compatibility**

This software release has been approved for use on the following devices.

	evice amily	Part Numbers		Device Specific Manuals and Guides
ET	Г80А	ET80A-0P5A1-000 ET80A-0P5A1-C00 ET80A-0P5A1-0F0 ET80A-0P5A2-000 ET80A-0P5A2-0F0 ET80A-0P5A2-CF0 ET80A-0P5A2-OOA ET80A-0P5A2-CFA	ET80A-0P5B2-CFA ET80A-0P5B3-00A ET80A-0P5B3-CFA ET80A-0P6B2-00A ET80A-0P6B3-CFA ET80A-0P8B2-CFA ET80A-0P8B3-CFA ET80A-0P6B2-000	ET8XX Support Page



	ET80A-0P5B2-000 ET80A-0P5B2-CF0	ET80A-0P6B3-CF0 ET80A-0P8B2-CF0	
	ET80A-0P5B2-00A	ET80A-0P8B3-CF0	
		1	
ET85B	ET85B-3P5A1-000	ET85B-3P5B2-00C	
	ET85B-3P5A2-000	ET85B-3P5B2-CFC	
	ET85B-3P5A2-0F0	ET85B-3P5B3-00C	
	ET85B-3P5A2-CF0	ET85B-3P6B2-00C	
	ET85B-3P5A2-00C	ET85B-3P8B2-CFC	
	ET85B-3P5A2-CFC	ET85B-3P6B2-000	
	ET85B-3P5B2-000	ET85B-3P8B2-CF0	
	ET85B-3P5B2-CF0		
ET85C	ET85C-3P5A2-CF0	ET85C-3P5B3-CFB	
	ET85C-3P5A2-00B	ET85C-3P6B3-CFB	
	ET85C-3P5A2-CFB	ET85C-3P8B3-CFB	
	ET85C-3P5B2-00B	ET85C-3P6B3-CF0	
	ET85C-3P5B2-CFB	ET85C-3P8B3-CF0	
	ET85C-3P5B3-00B		

## **Revision History**

_		
Rev	Description	Date
1.0	Initial revision	September 13, 2022