CANCEL Self Test

The CANCEL self test prints a configuration label (Figure 18).

To perform the CANCEL Self Test, complete these steps:

- **1.** Turn off (**O**) the printer.
- **2.** Press and hold CANCEL while turning on (I) the printer. Hold CANCEL until the first control panel light turns off.

A printer configuration label prints (Figure 18).

Z Series

Figure 18 • Sample Configuration Label

RZ Se	ries
PRINTER CONF	IGURATION
Zebra Technologies ZTC RZ400-200dpi ZPI ZBR2279583	-
+10. 2 IPS. +000. RFID MODE. CONTINUOUS. TRANSMISSIVE. THERMAL-TRANS	DARKNESS PRINT SPEED TEAR OFF PRINT MODE MEDIA TYPE SENSOR SELECT PRINT METHOD
+000. RFID HODE. CONTINUOUS. TRANSMISSIVE. TORNAL-TRANS. 1600. 33.01N 368MM MAINT OFF. NOT CONNECTED. BIDIRECTIONAL. R5232. 1 52700	PRINT WIDTH LABEL LENGTH MAXIMUM LENGTH EARLY WARNING USB COMM. PARALLEL COMM. SERIAL COMM.
8 BITS. NONE. XON/XOFF. NONE. 000. NORMAL_MODE.	DATA BITS PARITY
C, ZCHZPL II. FEED. FEED.	ZPL MODE MEDIA POWER UP HEAD CLOSE BACKFEED
000. +0000. DISABLED. 069. 073. 100. 000.	LABEL TOP LABEL TOP LEFT POSITION REPRINT MODE WEB S. MEDIA S. RIBBON S. TAKE LABEL MARK S. TAKE CABEL
033 176 216 013 DPSWFXM	MARK S. TRANS GAIN TRANS BASE TRANS BRIGHT RIBBON GAIN MARK GAIN MODES ENABLED MODES ENABLED RESOLUTION
832 8/MH FULL. R53 16.12 < 1.2. V37 38. CUSTOMIZED 11008k. S9392k. Nove	AND SCHEMA MARDWARE ID CONFIGURATION RAM
NONE. FW VERSION. 11/01/07. 16:50. DISABLED. 2.0. 600.	IDLE DISPLAY RTC DATE RTC TIME
	ZBI VERSION RFID VALID CTR RFID VOID CTR RFID READ PWR RFID WRITE PWR RFID WRITE PWR RFID TAG TYPE RFID TAG TYPE RFID HW VERSION
NO TAG FOUND. Gen2. 00000003. 0122. 022. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0122. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125. 0125.	PROG. POSITION PROG. POSITION NONRESET CNTR RESET CNTR1 RESET CNTR2 NONRESET CNTR RESET CNTR1 DESET CNTR1 DESET CNTP2
SELECTED ITEMS. MO 12592.06CXP10011	PASSWORD LEVEL 1.79400-002.D.VH1

R7 Series

FIRMWARE IN THIS PRINTER IS COPYRIGHTED

PAUSE Self Test

This self test can be used to provide the test labels required when making adjustments to the printer's mechanical assemblies or to determine if any printhead elements are not working. Figure 19 shows a sample printout.

To perform a PAUSE self test, complete these steps:

- **1.** Turn off (**O**) the printer.
- **2.** Press and hold PAUSE while turning on (I) the printer. Hold PAUSE until the first control panel light turns off.
 - The initial self test prints 15 labels at the printer's slowest speed, and then automatically pauses the printer. Each time PAUSE is pressed, an additional 15 labels print. Figure 19 shows a sample of the labels.




Figure 19 • PAUSE Test Label

- While the printer is paused, pressing CANCEL alters the self test. Each time PAUSE is pressed, 15 labels print at 6 in. (152 mm) per second.
- While the printer is paused, pressing CANCEL again alters the self test a second time. Each time PAUSE is pressed, 50 labels print at the printer's slowest speed
- While the printer is paused, pressing CANCEL again alters the self test a third time. Each time PAUSE is pressed, 50 labels print at 6 in. (152 mm) per second.
- While the printer is paused, pressing CANCEL again alters the self test a fourth time. Each time PAUSE is pressed, 15 labels print at the printer's maximum speed.
- To exit this self test at any time, press and hold CANCEL.

FEED Self Test

Different types of media may require different darkness settings. This section contains a simple but effective method for determining the ideal darkness for printing bar codes that are within specifications.

During the FEED self test, labels are printed at different darkness settings at two different print speeds. The relative darkness and the print speed are printed on each label. The bar codes on these labels may be ANSI-graded to check print quality.

The darkness value starts at three settings lower than the printer's current darkness value (relative darkness of -3) and increase until the darkness is three settings higher than the current darkness value (relative darkness of +3).

Depending on the dot density of the printhead, seven labels are printed at each of the following speeds:

- 203 dpi printers: 2 ips, 6 ips, and 10 ips
- 300 dpi printers: 2 ips, 6 ips, 8 ips
- 600 dpi printers: 2 ips, 4 ips

To perform a FEED self test, complete these steps:

- **1.** Print a configuration label to show the printer's current settings.
- **2.** Turn off (**O**) the printer.
- **3.** Press and hold FEED while turning on (I) the printer. Hold FEED until the first control panel light turns off.

The printer prints a series of labels (Figure 20) at various speeds and at darkness settings higher and lower than the darkness value shown on the configuration label.



Figure 20 • FEED Test Label

4. See Figure 21 and Table 21. Inspect the test labels and determine which one has the best print quality for your application. If you have a bar code verifier, use it to measure bars/spaces and calculate the print contrast. If you do not have a bar code verifier, use your eyes or the system scanner to choose the optimal darkness setting based on the labels printed in this self test.




Figure 21 • Bar Code Darkness Comparison

Table 21 • Judging Bar Code Quality

Print Quality	Description
Too dark	Labels that are too dark are fairly obvious. They may be readable but not "in-spec."
	 The normal bar code bars increase in size. The openings in small alphanumeric characters may fill in with ink. Pototed bar code bars and spaces run together.
Slightly dark	 Rotated bar code bars and spaces run together. Slightly dark labels are not as obvious. The normal bar code will be "in-spec." Small character alpha numerics will be bold and could be slightly filled in. The rotated bar code spaces are small when compared to

Print Quality	Description
"In-spec"	 The "in-spec" bar code can only be confirmed by a verifier, but it should exhibit some visible characteristics. The normal bar code will have complete, even bars and clear, distinct spaces. The rotated bar code will have complete, even bars and clear, distinct spaces. Although it may not look as good as a slightly dark bar code, the bar code will be "in-spec." In both normal and rotated styles, small alphanumeric characters look complete.
Slightly light	 Slightly light labels are, in some cases, preferred to slightly dark ones for "in-spec" bar codes. Both normal and rotated bar codes will be in spec, but small alphanumeric characters may not be complete.
Too light	 Labels that are too light are obvious. Both normal and rotated bar codes have incomplete bars and spaces. Small alphanumeric characters are unreadable.

Table 21 • Judging Bar Code Quality (Continued)

- 5. Note the relative darkness value and the print speed printed on the best test label.
- **6.** Add or subtract the relative darkness value from the darkness value specified on the configuration label. The resulting numeric value is the best darkness value for that specific label/ribbon combination and print speed.
- 7. If necessary, change the darkness value to the darkness value on the best test label.
- 8. If necessary, change the print speed to the same speed as on the best test label.

.