



SEE MORE. DO MORE.

DISMANTLING AND TREATMENT INFORMATION

WhereCall Product

Conforms to **Waste electrical and electronic equipment (WEEE)
2002/96/EC**

Category 3 product according Annex IA

Date: 10 October 2011

Zebra Technologies
2940 North 1st Street
San Jose, CA 95134
www.zebra.com

Reuse and treatment information

Material	Weight [g]	Weight [%]	Important Information
Waste Disposal (WD)			
Ceramic	0	0	
Subtotal	0	0	
Recovery Operations (RO)			
Leather	0	0	
Rubber / elastomere	0	0	
Sealant compound	0	0	
Wood	0	0	
Subtotal	0	0	
Re-Use (RU)			
Aluminium alloy cast	0	0	
Aluminium alloy wrought	0	0	
Battery	39.7	23.4	Remove battery
Cable	0	0	
Cable with plug	0	0	
Carton	0	0	
Copper	0	0	
Copper Alloy	0	0	
Gas	0	0	
Glass Optical	0	0	
Iron	0	0	
Liquid Crystal Displays	0	0	<100 cm ²
Magnesium alloy	0	0	
Magnetic material	0	0	
Metal nonferrous	0	0	
Paper	0	0	
Plastic	73.6	43.3	
Plug	0	0	
Printed circuit board	56.7	33.3	Remove Printed Circuit Board
Sintered material	0	0	
Steel	0	0	
Steel stainless	0	0	
Textile material	0	0	
Subtotal	170	100	
Re-Use (RU)			
Subtotal	0	0	
Total weight	170g	100%	

Product identification and selective treatment information



78 mm x 125 mm x 36 mm

This device complies with part 15 of the FCC rules and RSS-210 of Industry Canada. Operation is subject to the following conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference which may cause undesired operation.

FC Tested to Comply
with FCC Standards
FOR HOME OR OFFICE USE
FCC ID: N5QTFF-1000-00AA
WhereCall III Model TFF-1610
Canada 35861021866A
CE 0678

Product Description:

The WhereCall III is a palm-sized device in a yellow and gray colored case. A green colored actuator button is in the center of the device. A liquid crystal display (LCD) screen is located above the button. WhereCalls are powered by AA-size Lithium-Thionyl Chloride battery cells.

Dismantling Instructions

- A) Open case by removing two screws on front and four on back.
- B) Remove printed circuit board from case.
- C) Remove two batteries from battery holder.



Remove two (2) Screws from Front and four (4) Screws from Back



Remove two (2) Batteries

Remove Printed Circuit Board