


HC1 HEADSET COMPUTER QUICK REFERENCE GUIDE



Zebra reserves the right to make changes to any product to improve reliability, function, or design.

Zebra does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or by implication, estoppel, or otherwise under any patent right or patent, covering or relating to any combination, system, apparatus, machine, material, method, or process in which Zebra products might be used. An implied license exists only for equipment, circuits, and subsystems contained in Zebra products.

Warranty

For the complete Zebra hardware product warranty statement, go to:

<http://www.zebra.com/warranty>.

Service Information

If you have a problem using the equipment, contact your facility's Technical or Systems Support. If there is a problem with the equipment, they will contact the Zebra Global Customer Support at: <http://www.zebra.com/support>.

For the latest version of this guide go to: <http://www.zebra.com/support>.

Disclaimer

Read these instructions before using the HC1:

- Always wear safety glasses when using the HC1.
- Do not use the HC1 when operating a motor vehicle or when the inability to concentrate may present a danger to you or others.
- Discontinue using the HC1 if you feel drowsy or disorientated.
- Long term exposure to continuous loud audio may cause hearing damage. You should avoid extreme volume when using the device, especially for extended periods.
- Use only the power adapter provided by Zebra.
- The battery used by this HC1 is only available through Zebra.

Introduction

This Quick Reference Guide explains how to install and charge the battery, proper install the HC1 on the user's head and install accessories.

Unpacking


Carefully remove all protective material from around the HC1 and save the shipping container for later storage and shipping.

Verify that you received all equipment listed below:

- HC1 headset computer
 - Computer/Optical Pod Assembly
 - Firm Goods Assembly
- Lithium-ion battery (1950 or 4800 mAh)
- Speaker Module
- Camera (optional)
- Battery Cover (for 1950 or 4800 mAh battery)
- Quick Reference Guide.

Inspect the equipment for damage. If equipment is missing or damaged, contact the Zebra Global Customer Support immediately. See [Service Information on backcover](#) for contact information.

Features



Getting Started

Perform the following to setup the HC1 for the first time:



1. Install the battery
2. Charge the HC1
3. Determining dominant eye
4. Re-position Computer/Optical Pod Assembly
5. Re-position speaker module
6. Place the HC1 on head
7. Adjust head strap
8. Adjust optic pod.

Installing the Battery


To install the battery:

✓ **NOTE** These procedure show the HC1 with a 1950 mAh battery. Some HC1 configurations come with a 4800 mAh battery.

1. Insert the battery into the battery well with the battery notches facing down and the release latch facing up.



2. Rotate the battery into the battery well until it snaps into place. If the battery is charged, the HC1 turns on.
3. Align the battery door with the housing.
4. Close battery door.




5. Using a screwdriver or coin, turn the locking screw clockwise 1/4 turn to the lock position.

Charging the HC1


CAUTION Do not place on head while charging.

Before using the HC1, charge the battery. If a fully charged battery is installed, skip this procedure.


1. Press the release latches to remove the Firm Goods Assembly from the Computer/Optical Pod Assembly.



2. Connect the Charging Adapter to the Computer/Optical Pod Assembly.



3. Plug the Power Supply plug into the Charging Adapter.



4. Plug the Power Supply into a wall outlet.

5. Charge until the LED turns green.

LED State	Description
Slow Flashing Amber	HC1 is charging.
Solid Green	HC1 is fully charged.
Fast Flashing Amber	Charging Error.


6. Press the Charging Adapter release latches and remove the Charging Adapter from the Computer/Optical Pod Assembly.

Determining Dominant Eye

Eye dominance is the tendency to prefer visual input from one eye to the other. Most people are right-eye dominant; however in a small portion of the population neither eye is dominant. It is best to use your dominant eye when viewing the display.

To determine which eye is dominant:

1. Place hands together as shown forming a triangle.




2. Keeping both eyes open, focus on any distant object.
3. Maintaining focus on the object centered in the triangle, close your right eye. If the object is still in the triangle, you are left eye dominant.
4. Maintaining focus on the object centered in the triangle, close your left eye. If the object is still in the triangle, you are right eye dominant.
5. If the object is in the triangle with either eye then you are dominant eye neutral.
6. Repeat test to confirm.



Re-positioning the Computer/Optical Pod Assembly

From the factory, the HC1 is configured for left eye dominant. To switch the optical pod position:


1. If not already removed, press the release latches to remove the Firm Goods Assembly from the Computer/Optical Pod Assembly.



2. Rotate the Computer/Optical Pod Assembly 180°.



3. Reconnect the Firm Goods Assembly to the Computer/Optical Pod Assembly.




Re-positioning Speaker Module

✓ **NOTE** By default, the Speaker Module is installed on the right side. The user can switch the Speaker Module to the left side if desired.

If switching the position of the Computer/Optical Pod Assembly was shifted it might be necessary to re-position the Speaker Module.

1. Press release latch to remove Speaker Module from the Firm Good Assembly.




2. Align the Speaker Module on the opposite arm. Ensure that the Speaker Module is connected to the mating connector with the two contacts.
3. Press the Speaker Module in until it snaps into place.


Placing the HC1 on Head

The HC1 is worn on the head so that the main body of the device fits behind the base of the head with the strap sitting on top of the head.


1. If the HC1 is off, press the power button to turn it on.
2. Grasp the HC1 by the Firm Goods Assembly arms.
3. Pull the arms out to expand Firm Goods Assembly arms.
4. Position the HC1 over head.




5. Place the HC1 onto the head. The front of the headstrap must be positioned at the top of the forehead.



- 6. Re-position the back headstrap tab to position the height of the Computer/Optical Pod Assembly.
- 7. Re-position the left and right headstrap tabs to position the arms above the ears. Lengthen or shorten the head strap so that the ear loops are resting just above but not touching the ears.




- 8. Make sure the HC1 is balanced on head like you would a pair of eyeglasses.




Adjusting the Optical Boom

When adjusting the HC1 boom, hold the arm on the side opposite the boom when moving the boom up and down.




The HC1 pivot points allow the user to properly position the Optical Pod and to move the Optical Pod when the user does not need to use it.


The Coarse Pivot Point allows for moving the Optical Pod large distances. The Fine Pivot point allow for fine tuning of the position. The Pod Pivot point allow for positioning of the display for viewing.




Move the Optical Boom in or out to position under eye.




Position the optical boom so that the Optical Pod is positioned approximately two fingers distance from the eye wear.



The Optical Pod must be positioned so that it does not block the line of sight of the user.



1. Hold the HC1 with one hand and rotate the arm at the Coarse Pivot Point.
2. Hold the HC1 with one hand and rotate the arm at the Fine Pivot Point.
3. Repeat adjustments until the Optical Pod is two finger lengths away from safety glasses and out of the user's line of sight.
4. Adjust the optical boom to position the display left or right.
5. Rotate the Optical Pod for best viewing angle.



Focus Display

To focus the display:

1. Look into the display.
2. There are two display dials for controlling the focus. One on top and one on the bottom. With thumb and index finger, squeeze dials.
3. Rotate the display dials either clockwise or counter-clockwise until the display appears in focus.




If the Computer/Optical Pod Assembly was rotated, the display appears upside down. Say "My Computer" > "My Controls" > "Screen Rotation" > "Rotate Screen." Refer to the *HC1 User Guide* for information on how to flip the display image.


Basic Usage

Head Tracker Navigation

The HC1 contains 9-axis head tracking sensors that allow the user to move the objects on the display by moving their head up and down and left and right.




As the user moves head left or right, the image on the display scrolls accordingly. Moving the head up and down moves the image on the display accordingly.



Voice Control

The HC1 is equipped with voice recognition software that allows the user to control software functionality by speaking specific on-screen commands. Refer to the *HC1 User Guide* for more information.




Each Firm Goods arm contains a programmable user button. By default, when the user presses and releases either of the buttons, voice controls are turned off. A dialog box appears on the screen notifying the user.

Zebra recommends that the user turn off voice controls to eliminate any inadvertent commands due to noisy environments or communication with another person. Press and release the button to turn on voice controls.

Positioning Optical Pod When not in Use

The user can move the Optical Pod away from the face when it is not being used for long periods of time. Grasps the boom and rotate up and away from the face.




Accessories

Camera

Connect the optional Camera to either arm of the Firm Goods Assembly.

1. Attach the connector of the Camera to Accessory port on the Firm Goods Assembly.
2. Push in until it snaps into place.




3. Move camera left or right to position for best viewing.



microSD Card

The microSD card provides additional storage for data. To install a microSD card:

1. Press the Power button for one second to place the HC1 into suspend mode. The LED flashes red momentarily and then turns off.
2. Using a #1 Phillips screwdriver, remove the screw securing the card cover.



3. Lift the card cover.
4. Insert the microSD card into the card slot with the contacts facing down.





5. Close the card cover.
6. Secure the card cover using a #1 Phillips screwdriver.
7. Press the Power button to wake up the HC1.

Ear Buds

Ear Buds provide an optional solution for the user that requires ear protection to hear audio from the HC1.

To install the Ear Buds:

1. Remove the Speaker Module from the Firm Goods Assembly arm.
2. Attach the connector of the Ear Buds to Audio port on the Firm Goods Assembly arm.




3. Place ear buds into ears.
4. Route the Ear Bud wire so that it does not interfere with movement.

Remove Accessory

To remove the speaker, camera or ear bud:

1. Press the release button.



2. The accessory ejects slightly.
3. Remove the accessory.

Resetting the HC1

To reset the HC1 press the Power button for at least eight seconds. The display turns off and the the HC1 reboots.

Regulatory Information

This guide applies to Model Number HC170.

All Zebra devices are designed to be compliant with rules and regulations in locations they are sold and will be labeled as required.

Local language translations are available at the following website:

<http://www.zebra.com/support>

Any changes or modifications to Zebra equipment, not expressly approved by Zebra, could void the user's authority to operate the equipment.



CAUTION

Only use Zebra approved and UL Listed accessories, battery packs and battery chargers.

Zebra devices are professionally installed, the Radio Frequency Output Power will not exceed the maximum allowable limit for the country of operation.

Do NOT attempt to charge damp/wet mobile computers or batteries. All components must be dry before connecting to an external power source.

Declared maximum operating temperature: 50 °C.

Bluetooth® Wireless Technology

This is an approved Bluetooth® product. For more information or to view End Product Listing, please visit <https://www.bluetooth.org/tpg/listings.cfm>

Wireless Device Country Approvals

Regulatory markings, subject to certification, are applied to the device signifying the radio(s) is/are approved for use in the following countries: United States, Canada, Australia, and Europe ¹.

Please refer to the Declaration of Conformity (DoC) for details of other country markings. This is available at <http://www.zebra.com/doc>.

Note1: For 2.4 GHz or 5 GHz Products: Europe includes, Austria, Belgium, Bulgaria, Czech Republic, Cyprus, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Liechtenstein, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovak Republic, Slovenia, Spain, Sweden, Switzerland and the United Kingdom.



Operation of the device without regulatory approval is illegal.

Country Roaming

This device incorporates the International Roaming feature (IEEE802.11d) which will ensure the product operates on the correct channels for the particular country of use.

Frequency of Operation - FCC and IC

2.4 GHz Only

The available channels for 802.11 b/g operation in the US are Channels 1 to 13. The range of channels is limited by firmware.

Health and Safety Recommendations

Ergonomic Recommendations



CAUTION

In order to avoid or minimize the potential risk of ergonomic injury follow the recommendations below. Consult with your local Health & Safety Manager to ensure that you are adhering to your company's safety programs to prevent employee injury.

- Reduce or eliminate repetitive motion
- Maintain a natural position
- Reduce or eliminate excessive force
- Keep objects that are used frequently within easy reach
- Perform tasks at correct heights
- Reduce or eliminate vibration
- Reduce or eliminate direct pressure
- Provide adjustable workstations

- Provide adequate clearance
- Provide a suitable working environment
- Improve work procedures.

Note: The following section is only applicable for mobile computers.

Vehicle Installation

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles (including safety systems). Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Note: Connection to an alert device that will cause a vehicle horn to sound or lights to flash, on receipt of a call on public roads, is not permitted.

IMPORTANT

Before installing or using, check state and local laws regarding windshield mounting and use of equipment.

For safe Installation:

- Do not put your phone in a location that obstructs the drivers vision or interferes with the operation of the Vehicle. Do not cover an airbag.

Safety on the Road

Do not use the HC1 when operating any vehicle or when the inability to concentrate may present a danger to you or others.

Do not take notes or use the device while driving. Jotting down a “to do” list or flipping through your address book takes attention away from your primary responsibility, driving safely.

When driving a car, driving is your first responsibility - Give full attention to driving. Check the laws and regulations on the use of wireless devices in the areas where you drive. Always obey them.



Warnings for Use of Wireless Devices

Please observe all warning notices with regard to the usage of wireless devices.

Potentially Hazardous Atmospheres - Vehicles Use

You are reminded of the need to observe restrictions on the use of radio devices in fuel depots, chemical plants etc. and areas where the air contains chemicals or particles (such as grain, dust, or metal powders) and any other area where you would normally be advised to turn off your vehicle engine.

Safety in Aircraft

Switch off your wireless device whenever you are instructed to do so by airport or airline staff. If your device offers a 'flight mode' or similar feature, consult airline staff as to its use in flight.



Safety in Hospitals

Wireless devices transmit radio frequency energy and may affect medical electrical equipment.

Wireless devices should be switched off wherever you are requested to do so in hospitals, clinics or healthcare facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Pacemakers

Pacemaker manufacturers recommended that a minimum of 15 cm (6 inches) be maintained between a handheld wireless device and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with independent research and recommendations by Wireless Technology Research.

Persons with Pacemakers:

- Should ALWAYS keep the device more than 15 cm (6 inches) from their pacemaker when turned ON.
- Should not carry the device in a breast pocket.
- Should use the ear furthest from the pacemaker to minimise the potential for interference.
- If you have any reason to suspect that interference is taking place, turn OFF your device.

Other Medical Devices

Please consult your physician or the manufacturer of the medical device, to determine if the operation of your wireless product may interfere with the medical device.



RF Exposure Guidelines

Safety Information

Reducing RF Exposure - Use Properly

Only operate the device in accordance with the instructions supplied.

International

The device complies with internationally recognized standards covering human exposure to electromagnetic fields from radio devices. For information on "International" human exposure to electromagnetic fields refer to the Zebra Declaration of Conformity (DoC) at <http://www.zebra.com/doc>

Europe

Head Worn Devices

This device was tested for Head Mounted operation. Use only Zebra tested and approved accessories to ensure EU Compliance.

US and Canada

Head Worn Devices

This device was tested for typical body-worn operation. Use only Zebra tested and approved accessories to ensure FCC / IC Compliance. The use of third-party accessories may not comply with FCC / IC RF exposure compliance requirements, and should be avoided.

To satisfy US and Canadian RF exposure requirements, a transmitting device must operate with a minimum separation distance of 33.5 mm or more from a person's body.

Pour satisfaire aux exigences Américaines et Canadiennes d'exposition aux radiofréquences, un dispositif de transmission doit fonctionner avec une distance de séparation minimale de 33.5 mm ou plus de corps d'une personne.

LED Devices

Compliance statement for LED safety:

COMPLIES WITH IEC 60825-1:2001 (Ed.1.2) & IEC 62471:2006 (Ed.1.0); EN 62471:2008.

Power Supply

Use ONLY an approved UL LISTED ITE (IEC/EN 60950-1) power supply with electrical ratings: Output 5.4 VDC, min 3 A, with a maximum ambient temperature of at least 45 °C. Use of alternative power supply will invalidate any approvals given to this unit and may be dangerous.

Battery Information

Use only Zebra approved batteries. Accessories which have battery charging capability are approved for use with the following battery models:

Zebra BTRY-MC7XEAB0E (3.7 VDC, 1950 mAh)

Zebra BTRY-MC7XEAB0H (3.7 V DC, 4800 mAh)

Zebra rechargeable battery packs are designed and constructed to the highest standards within the industry.

However, there are limitations to how long a battery can operate or be stored before needing replacement. Many factors affect the actual life cycle of a battery pack, such as heat, cold, harsh environmental conditions and severe drops.

When batteries are stored over six (6) months, some irreversible deterioration in overall battery quality may occur. Store batteries at half of full charge in a dry, cool place, removed from the equipment to prevent loss of capacity, rusting of metallic parts and electrolyte leakage. When storing batteries for one year or longer, the charge level should be verified at least once a year and charged to half of full charge.

Replace the battery when a significant loss of run time is detected.

Standard warranty period for all Zebra batteries is one year, regardless if the battery was purchased separately or included as part of the mobile computer or bar code scanner. For more information on Zebra batteries, please visit: <http://www.zebra.com/batterybasics>

Battery Safety Guidelines

- The area in which the units are charged should be clear of debris and combustible materials or chemicals. Particular care should be taken where the device is charged in a non commercial environment.
- Follow battery usage, storage, and charging guidelines found in the HC1 User Guide.
- Improper battery use may result in a fire, explosion, or other hazard.
- To charge the mobile device battery, the battery and charger temperatures must be between +32 °F and +104 °F (0 °C and +40 °C).
- Do not use incompatible batteries and chargers. Use of an incompatible battery or charger may present a risk of fire, explosion, leakage, or other hazard. If you have any questions about the compatibility of a battery or a charger, contact Zebra support.
- Do not disassemble or open, crush, bend or deform, puncture, or shred.
- Severe impact from dropping any battery-operated device on a hard surface could cause the battery to overheat.
- Do not short circuit a battery or allow metallic or conductive objects to contact the battery terminals.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, or expose to fire, explosion, or other hazard.
- Do not leave or store the equipment in or near areas that might get very hot, such as in a parked vehicle or near a radiator or other heat source. Do not place battery into a microwave oven or dryer.
- Battery usage by children should be supervised.
- Please follow local regulations to promptly dispose of used re-chargeable batteries.
- Do not dispose of batteries in fire.
- Seek medical advice immediately if a battery has been swallowed.
- In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with large amounts of water and seek medical advice.
- If you suspect damage to your equipment or battery, contact Zebra Global Customer Support to arrange for inspection.

Use with Hearing Aids

When some wireless devices are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and wireless devices also vary in the amount of interference they generate. In the event of interference you may want to consult your hearing aid supplier to discuss solutions.

Radio Frequency Interference Requirements- FCC

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Radio Transmitters (Part 15)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radio Frequency Interference Requirements- Canada

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Radio Transmitters

This device complies with RSS 210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-210 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

Label Marking: The Term "IC:" before the radio certification only signifies that Industry Canada technical specifications were met.

The use of 2.4GHz RLAN's, for use through the EEA, have the following restrictions:



Marking and European Economic Area (EEA)

- Maximum radiated transmit power of 100 mW EIRP in the frequency range 2.400 - 2.4835 GHz.

Bluetooth® Wireless Technology for use through the EEA has the following restrictions:

- Maximum radiated transmit power of 100mW EIRP in the frequency range 2.400 - 2.4835 GHz

Statement of Compliance

Zebra hereby, declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC and 2011/65/EU. A Declaration of Conformity may be obtained from <http://www.zebra.com/doc>.

TURKISH WEEE Statement of Compliance

EEE Yönetmeliğine Uygundur

Brazil

Declarações Regulamentares para

Nota: “A marca de certificação se aplica ao Transceptor, modelo HC170. Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.”

Para maiores informações sobre ANATEL consulte o site: www.anatel.gov.br

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.

Este produto está homologado pela Anatel, de acordo com os procedimentos regulamentados pela Resolução n°242/2000 e atende aos requisitos técnicos aplicados, incluindo os limites de exposição da Taxa de Absorção Específica referente a campos elétricos, magnéticos e eletromagnéticos de radiofrequência, de acordo com as Resoluções n° 303/2002 e 533/2009.

Este dispositivo está em conformidade com as diretrizes de exposição à radiofrequência quando posicionado pelo menos 0 centímetros de distância do corpo. Para maiores informações, consulte o site da Anatel.



Waste Electrical and Electronic Equipment (WEEE)

English: For EU Customers: All products at the end of their life must be returned to Zebra for recycling. For information on how to return product, please go to:

<http://www.zebra.com/weee>.

Français : Clients de l'Union Européenne : Tous les produits en fin de cycle de vie doivent être retournés à Zebra pour recyclage. Pour de plus amples informations sur le retour de produits, consultez : <http://www.zebra.com/weee>.

Español: Para clientes en la Unión Europea: todos los productos deberán entregarse a Zebra al final de su ciclo de vida para que sean reciclados. Si desea más información sobre cómo devolver un producto, visite: <http://www.zebra.com/weee>.

Deutsch: Für Kunden innerhalb der EU: Alle Produkte müssen am Ende ihrer Lebensdauer zum Recycling an Zebra zurückgesandt werden. Informationen zur Rücksendung von Produkten finden Sie unter <http://www.zebra.com/weee>.

Italiano: per i clienti dell'UE: tutti i prodotti che sono giunti al termine del rispettivo ciclo di vita devono essere restituiti a Zebra al fine di consentirne il riciclaggio. Per informazioni sulle modalità di restituzione, visitare il seguente sito Web: <http://www.zebra.com/weee>.

Português: Para clientes da UE: todos os produtos no fim de vida devem ser devolvidos a Zebra para reciclagem. Para obter informações sobre como devolver o produto, visite: <http://www.zebra.com/weee>.

Nederlands: Voor klanten in de EU: alle producten dienen aan het einde van hun levensduur naar Zebra te worden teruggezonden voor recycling. Raadpleeg <http://www.zebra.com/weee> voor meer informatie over het terugzenden van producten.

Polski: Klienci z obszaru Unii Europejskiej: Produkty wycofane z eksploatacji należy zwrócić do firmy Zebra w celu ich utylizacji. Informacje na temat zwrotu produktów znajdują się na stronie internetowej <http://www.zebra.com/weee>.

Čeština: Pro zákazníky z EU: Všechny produkty je nutné po skončení jejich životnosti vrátit společnosti Zebra k recyklaci. Informace o způsobu vrácení produktu najdete na webové stránce: <http://www.zebra.com/weee>.

Eesti: EL klientidele: kõik tooted tuleb nende eluea lõppedes tagastada taaskasutamise eesmärgil Zebra'ile. Lisainformatsiooni saamiseks toote tagastamise kohta külastage palun aadressi: <http://www.zebra.com/weee>.

Magyar: Az EU-ban vásárlóknak: Minden tönkrement termékét a Zebra vállalatához kell eljuttatni újrahasznosítás céljából. A termék visszajuttatásának módjával kapcsolatos tudnivalóért látogasson el a <http://www.zebra.com/weee> weboldalra.

Slovenski: Za kupce v EU: vsi izdelki se morajo po poteku življenjske dobe vrniti podjetju Zebra za reciklažo. Za informacije o vračilu izdelka obiščite: <http://www.zebra.com/weee>.

Svenska: För kunder inom EU: Alla produkter som uppnått sin livslängd måste returneras till Zebra för återvinning. Information om hur du returnerar produkten finns på <http://www.zebra.com/weee>.

Suomi: Asiakkaat Euroopan unionin alueella: Kaikki tuotteet on palautettava kierrätettäväksi Zebra-yhtiöön, kun tuotetta ei enää käytetä. Lisätietoja tuotteen palauttamisesta on osoitteessa <http://www.zebra.com/weee>.

Dansk: Til kunder i EU: Alle produkter skal returneres til Zebra til recirkulering, når de er udtjent. Læs oplysningerne om returnering af produkter på: <http://www.zebra.com/weee>.

Ελληνικά: Για πελάτες στην Ε.Ε.: Όλα τα προϊόντα, στο τέλος της διάρκειας ζωής τους, πρέπει να επιστρέφονται στην Zebra για ανακύκλωση. Για περισσότερες πληροφορίες σχετικά με την επιστροφή ενός προϊόντος, επισκεφθείτε τη διεύθυνση <http://www.zebra.com/weee> στο Διαδίκτυο.

Malti: Għal klijenti fl-UE: il-prodotti kollha li jkunu waslu fl-aħħar tal-ħajja ta' l-użu tagħhom, iridu jiġu rritornati għand Zebra għar-riċiklaġġ. Għal aktar tagħrif dwar kif għandek tirritorna l-prodott, jekk jogħġbok żur: <http://www.zebra.com/weee>.

Slovenčina: Pre zákazníkov z krajín EU: Všetky výrobky musia byť po uplynutí doby ich životnosti vrátené spoločnosti Zebra na recykláciu. Bližšie informácie o vrátení výrobkov nájdete na: <http://www.zebra.com/weee>.

Lietuvių: ES vartotojams: visi gaminiai, pasibaigus jų eksploatacijos laikui, turi būti grąžinti utilizuoti į kompaniją „Zebra“. Daugiau informacijos, kaip grąžinti gaminį, rasite: <http://www.zebra.com/weee>.

Latviešu: ES klientiem: visi produkti pēc to kalpošanas mūža beigām ir jānogādā atpakaļ Zebra otrreizējai pārstrādei. Lai iegūtu informāciju par produktu nogādāšanu Zebra, lūdzu, skatiet: <http://www.zebra.com/weee>.

Türkçe: AB Müşterileri için: Kullanım süresi dolan tüm ürünler geri dönüşürme için Zebra'ya iade edilmelidir. Ürünlerin nasıl iade edileceği hakkında bilgi için lütfen şu adresi ziyaret edin: <http://www.zebra.com/weee>

Software Support

Zebra wants to ensure that customers have the latest release of entitled software at the time of product purchase.

To confirm that your Zebra device shipped with the latest release of entitled software, visit: www.zebra.com/support. Check for the latest software from *Software Downloads > Product Line/Product > Go*.

If your device does not have the latest entitled software release as of your product purchase date, please e-mail a request to Zebra at: entitlementservices@zebra.com.

You must include the following essential device information with your request:

- Model number
- Serial number
- Proof of purchase
- Title of the software download you are requesting.

If it is determined by Zebra that your device is entitled to the latest software release, you will receive an e-mail containing a link directing you to a Zebra Web site to download the appropriate software.



Zebra Technologies Corporation
Lincolnshire, IL U.S.A.
<http://www.zebra.com>

Zebra and the stylized Zebra head are trademarks of ZIH Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners.

©2015 ZIH Corp and/or its affiliates. All rights reserved.



72-165008-03 Rev. A - May 2015

